Wiring Electrical equipment Power supply L
Heating Appliances Knowledge base

Are you here: home > Knowledge base > Tricks and Leadership

How to calculate the length of a nichrome wire

In the practice of a home master, one has to repair or design heating devices. It can be various furnaces, heaters, soldering irons and cutters. Most often, spirals or nichrome wire are used for this. The main task in this case is to determine the length and cross section of the material. In this article, we will talk about how to calculate the length of a nichrome wire or spiral by power, resistance and temperature.

Content:

Basic information and brands of nichrome

Calculation Methods

By resistance

By temperature

Conclusion

Basic information and brands of nichrome

Nickel is an alloy of nickel and chromium with the addition of manganese, silicon, iron, aluminum. For this material, the parameters depend on the specific ratio of substances in the alloy, but on average lie in the range:

```
electrical resistivity - 1.05-1.4 Ohm * mm²/ m (depending on the grade of alloy); temperature coefficient of resistance - (0.1-0.25) \cdot 10<sup>-3</sup> TO<sup>-1</sup>; operating temperature - 1100 ° C; melting point - 1400 ° C;
```

In the tables, resistivity is often given in $\mu\Omega$ * m (or 10⁻⁶ Ohm * m) - the numerical values are the same, the difference in dimension.




There are currently two of the most common brands of nichrome wire:

X20H80. It consists of 74% nickel and 23% chromium, as well as 1% iron, silicon and manganese. Conductors of this brand can be used at temperatures up to 1250 $^{\circ}$ C, melting point - 1400 $^{\circ}$ C. It also has a high electrical resistance. The alloy is used for the manufacture of elements of heating devices. The specific resistance is 1.03-1.18 μOhm \cdot m;

X15H60. Composition: 60% nickel, 25% iron, 15% chromium. Operating temperature no more than $1150\,^{\circ}$ C. Melting point - $1390\,^{\circ}$ C. It contains more iron, which increases the magnetic properties of the alloy and increases its corrosion resistance.

You will learn more about the grades and properties of these alloys from GOST 10994-74, GOST 8803-89, GOST 12766.1-90 and others.

As already mentioned, nichrome wire is used everywhere where heating elements are needed. High resistivity and melting point make it possible to use nichrome as the basis for various heating elements, from a kettle or hairdryer to a muffle furnace.



Calculation Methods

By resistance

Let's figure out how to calculate the length of a nichrome wire in terms of power and resistance. The calculation begins with determining the required power. Imagine that we need a nichrome thread for a small soldering iron with a power of 10 watts, which will work from a 12V power supply. To do this, we have a wire with a diameter of 0.12 mm.



The simplest calculation of nichrome length in power without taking into account heating is performed as follows:

We determine the current strength:

$$P = UI$$

$$I = P / U = 10/12 = 0.83 A$$

Calculation of the resistance of a nichrome wire is carried out by Ohm's law:

$$R = U / I = 12 / 0.83 = 14.5 Ohm$$

The length of the wire is:

$$I = SR / \rho$$
,

where S is the cross-sectional area, ρ – resistivity.

Or according to this formula:

$$I = (R\pi d2) / 4\rho$$

But first you need to calculate the resistivity for nichrome wire with a diameter of 0.12 mm. It depends on the diameter - the larger it is, the less resistance.

$$L = (14.5 * 3.14 * 0.12 ^ 2) / 4 * 1.1 = 0.149m = 14.9cm$$

The same can be taken from GOST 12766.1-90 table. 8, where a value of 95.6 Ohm / m is indicated, if you count it, you get almost the same thing:

$$L = R_{required} / R_{tabl} = 14.4 / 95.6 = 0.151m = 15.1cm$$

For a 10-watt heater that is powered by 12V, you need 15.1cm.

If you need to calculate the number of turns of a spiral to twist it from a nichrome wire of this length, then use the following formulas:

Length of one turn:

$$I_1 = \pi (D + d / 2),$$

Number of turns:

$$N = L / (\pi (D + d / 2)),$$

where L and d are the length and diameter of the wire, D is the diameter of the rod on which the spiral will be wound.

Suppose we will wind a nichrome wire onto a rod with a diameter of 3 mm, then the calculations are carried out in millimeters:

$$N = 151 / (3.14 (3 + 0.12 / 2)) = 15.71 turns$$

But at the same time, one must take into account whether or not nichrome of such a cross section can withstand this current. Detailed tables for determining the maximum permissible current at a certain

temperature for specific sections are given below. In simple words - you determine how many degrees the wire should heat up and select its cross section for the rated current.

Диаметр проволоки, мм	٥.	Температура нагревателя, ^о С										
	Площадь поперечного сечения проволоки, мм²	200	400	600	700	800	900	1000				
	Площадь поперечн сечения проволон	Максимальная допустимая сила тока, А										
5	19,6	52	83	105	124	146	173	206				
4	12,6	37	60	80	93	110	129	151				
3	7,07	22,3	37,5	54,5	64	77	88	102				
2,5	4,91	16,6	27,5	40	46,6	57,5	66,5	73				
2	3,14	11,7	19,6	28,7	33,8	39,5	47,0	51				
1,8	2,54	10	16,9	24,9	29	33,1	39	43,2				
1,6	2,01	8,6	14,4	21	24,5	28	32,9	36				
1,5	1,77	7,9	13,2	19,2	22,4	25,7	30	33				
1,4	1,54	7,25	12	17,4	20	23,30	27	30				
1,3	1,33	6,6	10,9	15,6	17,8	21	24,4	27				
1,2	1,13	6	9,8	14	15,8	18,7	21,6	24,3				
1,1	0,95	5,4	8,7	12,4	13,9	16,5	19,1	21,5				
1,0	0,785	4,85	7,7	10,8	12,1	14,3	16,8	19,2				
0,9	0,636	4,25	6,7	9,35	10,45	12,3	14,5	16,5				
0,8	0,503	3,7	5,7	8,15	9,15	10,8	12,3	14				

ž,	٥.	Температура нагревателя, °С										
Диаметр проволоки, мм	Площадь поперечного сечения проволоки, мм?	200	400	600	700	800	900	1000				
Диа проб	Площадь поперечн сечения проволон	Максимальная допустимая сила тока, А										
0,75	0,442	3,4	5,3	7,55	8,4	9,95	11,25	12,85				
0,7	0,385	3,1	4,8	6,95	7,8	9,1	10,3	11,8				
0,65	0,342	2,82	4,4	6,3	7,15	8,25	9,3	10,75				
0,6	0,283	2,52	4	5,7	6,5	7,5	8,5	9,7				
0,55	0,238	2,25	3,55	5,1	5,8	6,75	7,6	8,7				
0,5	0,196	2	3,15	4,5	5,2	5,9	6,75	7,7				
0,45	0,159	1,74	2,75	3,9	4,45	5,2	5,85	6,75				
0,4	0,126	1,5	2,34	3,3	3,85	4,4	5	5,7				
0,35	0,096	1,27	1,95	2,76	3,3	3,75	4,15	4,75				
0,3	0,085	1,05	1,63	2,27	2,7	3,05	3,4	3,85				
0,25	0,049	0,84	1,33	1,83	2,15	2,4	2,7	3,1				
0,2	0,0314	0,65	1,03	1,4	1,65	1,82	2	2,3				
0,15	0,0177	0,46	0,74	0,99	1,15	1,28	1,4	1,62				
0,1	0,00785	0,1	0,47	0,63	0,72	0,8	0,9	1				

Also note that if the heater is inside the liquid, then the current can be increased by 1.2-1.5 times, and if in a confined space, then vice versa - reduced.

By temperature

The problem of the above calculation is that we consider the resistance of a cold spiral along the diameter of the nichrome thread and its length. But it depends on the temperature, while it is also necessary to consider under what conditions it will be possible to achieve it. If this calculation is still applicable for cutting foam or for a heater, then it will be too coarse for a muffle furnace.



We give an example of nichrome calculations for a furnace.

First, determine its volume, let's say 50 liters, then determine the power, for this there is an empirical rule:

Then in our case:


$$P = p_{emp}^* V = 50 * 100 = 5 kW.$$

Next, we consider the current strength and resistance:

For 220V:

$$I = 5000/220 = 22.7 \text{ Amps}$$

$$R = 220 / 22.7 = 9.7 Ohms$$



For 380V when connecting the spirals with a star, the calculation will be as follows.

Divide the power into 3 phases:

$$Pf = 5/3 = 1.66 \text{ kW per phase}$$

When connected by a star, 220V is applied to each branch (phase voltage, it may differ depending on your electrical installation), then the current:

Resistance:

$$R = 220 / 7.54 = 29.1 Ohm$$

For a triangle connection, we calculate according to a linear voltage of 380V:

To determine the diameter, the specific surface power of the heater is taken into account. We calculate the length, we take the resistivity from the table. 8. GOST 12766.1-90, but first we define the diameter.

To calculate the specific surface power of the furnace using the formula.

$$\beta_{\text{gon}} = \beta_{\text{ph}} \cdot \alpha$$

Bet (depends on the heat-absorbing surface) and a (coefficient of radiation efficiency) are selected according to the following tables.

Температура тепловоспринимающей	β _{эф} · Вт/см² при температуре нагревателя, °С									
поверхности, °С	800	850	900	950	1000					
100	6,1	7,3	8,7	10,3	12,5					
200	5,9	7,15	8,55	10,15	12,0					
300	5,65	6,85	8,3	9,9	11,7					
400	5,2	6,45	7,85	9,45	11,25					
500	4,5	5,7	7,15	8,8	10,55					
600	3,5	4,7	6,1	7,7	9,5					
700	2	3,2	4,6	6,25	8,05					
800	8	1,25	2,65	4,2	6,05					
850	8	8	1,4	3,0	4,8					
900		0		1,55	3,4					
950	-	-		-	1,8					
1000	*	-	-	-	(#F					
1050	-	-	-	-	35					
1100	-	-	-	*1						
1150		-	8	-	1070					
1200	8	9		20	833					
1300	2	-	- 2	20	828					

			см² при темі агревателя,			
1050	1100	1150	1200	1250	1300	1350
14,15	16,4	19,0	21,8	24,9	28,4	36,3
14,0	16,25	18,85	21,65	24,75	28,2	36,1
13,75	16,0	18,6	21,35	24,5	27,9	35,8
13,3	15,55	18,1	20,9	24,0	27,45	35,4
12,6	14,85	17,4	20,2	23,3	26,8	34,6
11,5	13,8	16,4	19,3	22,3	25,7	33,7
10,0	12,4	14,9	17,7	20,8	24,3	32,2
8,1	10,4	12,9	15,7	18,8	22,3	30,2
6,85	9,1	11,7	14,5	17,6	21,0	29,0
5,45	7,5	10,3	13	16,2	19,6	27,6
3,85	6,15	8,65	11,5	14,5	18,1	26,0
2,05	4,3	6,85	9,7	12,75	16,25	24,2
9	2,3	4,8	7,65	10,75	14,25	22,2
.9	(ie.	2,55	5,35	8,5	12,0	19,8
24	(60)		2,85	5,95	9,4	17,55
17	35	8	a	3,15	6,55	14,55
		8		-	- 3	7,95

Размещение нагревателей	Коэффициент α
Проволочные спирали, полузакрытые в пазах футеровки	0,16 - 0,24
Проволочные спирали на полочках в трубках	0,30 - 0,36
Проволочные зигзагообразные (стержневые) нагреватели	0,60 - 0,72
Ленточные зигзагообразные нагреватели	0,38 - 0,44
Ленточные профилированные (ободовые) нагреватели	0,56 - 0,7

So, to heat the furnace to 1000 degrees, take the spiral temperature of 1100 degrees, then according to the selection table B_{ef} choose a value of 4.3 W / cm², and according to the selection table of coefficient a - 0.2.

$$AT_{additional} = B_{ef}^* a = 4.3 * 0.2 = 0.86 W / cm^2 = 0.86 * 10 ^ 4 W / m^2$$

The diameter is determined by the formula:

$$d = \sqrt[3]{\frac{4 \cdot \rho_t \cdot P^2}{\pi^2 \cdot U^2 \cdot \beta_{\text{AOB}}}}$$

 R_t - the specific resistance of the heater material at a given t is determined according to GOST 12766.1, table 9 (shown below).

Марка		Значения поправочного коэффициента Rt/R20 при температуре нагрева, град. С													
сплава	20	100	200	300	400	500	600	700	800	900	1000	1100	1200	1300	1400
X15H60	1,000	1,013	1,029	1,046	1,062	1,074	1,083								
X15H60-H	1,000	1,013	1,029	1,046	1,062	1,074	1,083	1,083	1,089	1,097	1,105	1,114		-	-
Х15Ю5	1,000	1,004	1,013	1,025	1,041	1,062	1,090	1,112	1,126	1,135	1,140				
X23Ю5	1,000	1,002	1,007	1,013	1,022	1,036	1,056	1,063	1,067	1,072	1,076	1,079	1,080	1,083	1,086
Х23Ю5Т	1,000	1,002	1,007	1,013	1,022	1,036	1,056	1,063	1,067	1,072	1,076	1,079	1,080	1,083	1,086
Х27Ю5Т	1,000	1,002	1,005	1,010	1,015	1,025	1,030	1,033	1,035	1,040	1,040	1,041	1,043	1,045	
X20H80-H	1,000	1,006	1,015	1,022	1,029	1,032	1,023	1,016	1,015	1,017	1,025	1,033	1,040		
хн70Ю-н	1,000	1,004		***	***	1,052	1,053	1,036	1,015	1,016	1,016	1,023	1,031		
ХН20ЮС	1,000	1,035	1,075	1,110	1,145	1,180	1,210	1,230	1,250	1,270	1,290	1,310			

For nichrome X80N20 - 1,025

$$R_t = p_{20} R_{1000} = 1.13 * 10 ^ 6 * 1.025 = 1.15 * 10 ^ 6 Ohm / mm$$

Then to connect to a three-phase network according to the "Star" scheme:

$$d = 1.23 \text{ mm}$$

The length is calculated by the formula:

$$l = \sqrt[3]{\frac{P \cdot U^2}{4 \cdot \pi \cdot \rho_t \cdot \beta_{\text{don}}^2}}$$

$$L = 42m$$

Check the values:

$$L = R / (p * k) = 29.1 / (0.82 * 1.033) = 34m$$

The values differ due to the high temperature of the spiral; the check does not take into account a number of factors. Therefore, we take for the length of 1 spiral - 42m, then for three spirals you need 126 meters of 1.3 mm nichrome.

Conclusion

Thus, you can calculate the length of the wire for a nichrome spiral and determine the desired diameter by power, cross-section and temperature. It is important to consider:

environmental conditions;

location of heating elements;

spiral temperature;

temperature to which the surface should be heated and other factors.

Even the above calculation, despite its complexity, cannot be called sufficiently accurate. Because the calculation of heating elements is a continuous thermodynamics, and a number of factors can be cited that influence its results, for example, thermal insulation of a furnace and so on.

In practice, after evaluating the spirals, they add or remove, depending on the result, or use temperature sensors and devices to adjust it.

Related materials:

How to make an induction boiler yourself

Calculation of cable cross-section by power and current

How to calculate wire resistance



Add a comment

Other Related Articles



How to lower constant and alternating voltage - an overview of ways



How to increase direct and alternating voltage



How to get electricity from the earth and is it possible

Calculators

NEW ON THE SITE



Why connect the hood in the bathroom?



Is it possible to connect PVA and VVG using PPE cans?



Will a self-regulating heating cable save moisture?



How to connect a TV 100 volt 142 watts from the onboard network 12V?



Problems with a two-key light switch in the bathroom and toilet



Why do devices buzz when plugged in?



Can I continue to use the power cord after damage?

CONTACT US: chinageox@gmail.com

CONTACT US

map of site

Sitemap