Limit/Home Switches



Stepper Motors

Note: Run a Jumper Wire from Pin 4 (E) to Spindle Chassis. Not show in diagram