

ATA 32-21-00 - LANDING GEAR - NOSE GEAR ASSEMBLY

SYNTHETIC TEST DOCUMENT - NOT A REAL MANUAL

1. Torque Specifications

The nose gear assembly retaining bolt (P/N SYN-32210-01) shall be torqued to 120 Nm +/- 5 Nm, applied in two stages.

Lubricate threads with approved grease (SYN-LUBE-4) prior to installation.

2. Inspection Interval

Inspect nose gear seal integrity every 400 flight hours or 90 days, whichever occurs first.

3. Safety Warning

WARNING: Ensure aircraft is on jacks and hydraulic pressure is relieved before removing the retaining bolt.

ATA 24-10-00 - ELECTRICAL POWER - MAIN BATTERY BUS

SYNTHETIC TEST DOCUMENT - NOT A REAL MANUAL

1. Isolation Procedure

Toggle main battery switches to the OFF position before inspecting any primary electrical bus in the forward avionics bay.

2. Reset Procedure

Following a bus trip event (fault code FLT-24-5), reset the main battery bus switch and confirm nominal voltage (27.5V DC +/- 1V) before returning aircraft to service.

ATA 79-00-00 - ENGINE OIL SYSTEM

SYNTHETIC TEST DOCUMENT - NOT A REAL MANUAL

1. Oil Specification

Use only approved synthetic turbine oil, specification SYN-OIL-5606. Do not mix with mineral-based oils.

2. Servicing Interval

Check oil quantity every 50 flight hours. Top up if below the MIN mark on the sight gauge; do not exceed MAX.

ATA 53-10-00 - FUSELAGE - SKIN PANEL SURFACE DAMAGE ASSESSMENT

SYNTHETIC TEST DOCUMENT - NOT A REAL MANUAL

1. Crack

Hairline surface cracks $\leq 5\text{mm}$ length, non-propagating, and outside principal structural element (PSE) zones are within limits pending engineering review within the next 10 flight hours. Any crack exceeding 5mm, or located within a PSE zone, requires immediate grounding and structural repair.

2. Dent

Smooth dents with a depth-to-diameter ratio of 1:20 or greater and maximum depth $\leq 3\text{mm}$ are within limits. Sharp-edged dents, or dents exceeding this ratio, require blend-out repair or panel replacement before further flight.

3. Scratch

Surface scratches not penetrating the clad layer (depth $\leq 0.05\text{mm}$) require touch-up paint only. Scratches penetrating the base metal require corrosion protection treatment within 24 hours of discovery.

4. Paint Peel-Off

Localized paint peel-off under 50 sq cm with no exposed corrosion requires repaint at next scheduled maintenance. Peel-off exceeding this area, or exposing corrosion, requires immediate corrosion inspection per section 6 below.

5. Missing Fastener Head

Any missing or sheared fastener head is not within limits. Aircraft is grounded until the fastener is replaced with an approved equivalent (see IPC) and all adjacent fasteners are inspected for the same defect.

6. Corrosion

Level 1 surface corrosion (light, no measurable material loss) may be treated and monitored at next scheduled check. Level 2 or Level 3 corrosion (measurable pitting or material loss) requires immediate structural engineering assessment and grounds the aircraft pending disposition.

7. Safety Warning

WARNING: Do not apply load to a panel exhibiting a crack or corrosion pending engineering disposition. Photograph and measure all damage prior to any cleaning or paint removal.