

DS1813 has internal pullup.
This reset circuit is bad and wrong,
and will be replaced with a proper one in the final version.
It works for now so long as I don't execute a
reset instruction, or encounter a double bus fault.

PATA Interface





File: pata.kicad_sch

Memory and DUART



File: memory-duart.kicad_sch





Interrupts should work after inverting
active high INTRQ, but I have not tested it yet

