
How I calibrated the Futer Sensor

Since the Futelk Load Cell can measure pulling and pushing force I calibrated the sensor for both (i.e. its full range) So I will go over both

For Pushing:


1) Setup the Device in this configuration



@ course sesses to Electronics board and then turn on PSU (+15V)



- 3 bet a set of Known weights to place on the top
 - 1) I used a combination of weights in the lab and gym weights I had (disk gym weights work great for this)
 - 2) Ideally you want weights with a consistent increment (i.e. $OK_3 \rightarrow IK_3 \rightarrow 2K_5 \cdots$)
- 9) Add the Known weight and second the voltage value



Note: You can record voltage manually (i.e. from arduino) or you can do this with Labview to generate a txt.file of data (recommended)

check out Calibration Data Collection. vi under Practice Files (github)

			(5)								HL																								
					Not	e:	The	. ia	leal	h	'ay	to	ca	یا اه د	ate	15	ωı	ith	. Į	oad	ling	. ar	nd	امن	oadi'	ng	phas	es /							
			\	Nha add and	t I we rea	me eight cordin	an , re	by cord lata.	thi dat	s 15	s yo vntil	o v	disc ov g	crete get	ely to	you	۲ ۲	max	W	eigh	+ a	nd	the		ου .	unla	oad	by	discr	etcl	ر م لا	emo√	ing	weig	ht
-	,	TF	1	· <u>·</u> -	μ ω	todd eight Lecord value	→		159	<u>3</u> T.	ı _	μ ω	Add eight Zecord value	→		1 Fg	3		Ren Wei	ione ight ord alve		E	F3		Rem wer	ou gut ord		18.] _ _	Remove weight recorr	i. † •		l.	i
· ·	• •	•				·hase	· 	·. 	· ·	•				·		· ·				· ·	· · ·	· ·	· ·		•	•	pading	F	hase				· -	· ·	/
			Œ	5) F	inall impol	ly o	isi'ng He	y' dat	יטר ים	pro and	g can po tion	n o erfoi	rm	hoice a	e (lire	Mat ac	regr	ess	thor ion 1	') +e	100	btai d (1	'n Ka \												
					th	lin	ar	lire		qual	hon	th	at	rei	a res		OITA	ges	. ''				. , ,												
		<u> </u>			lling			Dex	· (° -	·^-	this		۰۰۸fi	iq Uſ	atio.	^ _																			
			(<u>v</u>	sétu(P 41		DEV		-, 	,,,,,,	!///	111) wy	~	Fü	× tl	i t	₽₽	to	som	ethin	ا و	ike	 . t	able	wiit	n cl	lamps	š					
											Fu	iteK ond ell													aca.	to_									

Do 2 -6 just as the Pushing but in this configuration

How I calibrated the Omega sensor:

For this sensor I used the calibration file that is included with the HX711-ADC arduino libra.

(I will add this file on github as well under Arduino codes as Calibration ino)

① To setup and run this code I think did this:

• Placing the whole device

box is take

not level with the gripping area)

2) Once that is done, I verified that the readings were good against a scale (you can also measure the readings against the Setup something like this:

Calibrated Futer Sensor)

Setup something like this:

. Make sure the readings match or are close