Introduction

Thanks to zxystd for providing IntelBluetoothFirmware, which let the native Intel Bluetooth work. However, the current Intel BT driver does not support some Bluetooth devices. Here are some suggestions for better BT experience:

- Insert a USB Bluetooth / Disable the original one
- Solder D+ and D- wires to the WLAN_LTE slot
- Solder D+ and D- wires to the fingerprint slot

Insert a USB Bluetooth / Disable the original one

- Buy and insert a supported BT dongle model from BrcmPatchRAM README
- For Clover users:
 - Replace /CLOVER/ACPI/patched/SSDT-USB.aml with SSDT-USB-USBBT.aml
 - Delete BlueToolFixup.kext,IntelBTPatcher.kext, IntelBluetoothFirmware.kext, and IntelBluetoothInjector.kext in /CLOVER/kexts/
 - * These steps are for disabling the internal Bluetooth
 - Download and add BlueToolFixup.kext (macOS12), BrcmBluetoothInjector.kext (< macOS12), BrcmFirmwareData.kext, and BrcmPatchRAM3.kext to /CLOVER/kexts/Other/ (Don't need to do this step if you just want to disable the embedded Intel Bluetooth)
 - Rebuild kextcache and restart
- For OC users:
 - Add SSDT-USB-USBBT.aml to /OC/ACPI/
 - Download and add BlueToolFixup.kext (macOS12), BrcmBluetoothInjector.kext (< macOS12), BrcmFirmwareData.kext, and BrcmPatchRAM3.kext to /OC/Kexts/ (Don't need to do this step if you just want to disable the embedded Intel Bluetooth)
 - Open /OC/config.plist, change the following code:

• And then change the following code:

• Don't forget to disable Intel Bluetooth kexts, change the following code:

```
<dict>
     <key>Arch</key>
     <string>x86_64</string>
```

```
<key>BundlePath</key>
    <string>BlueToolFixup.kext</string>
    <key>Comment</key>
    <string>Force BlueTool to skip firmware update on Monterey</string>
    <key>Enabled</key>
   <true/>
   <false/>
   <key>ExecutablePath</key>
    <string>Contents/MacOS/BlueToolFixup</string>
    <key>MaxKernel</key>
    <string></string>
    <key>MinKernel</key>
    <string>21.0.0</string>
    <key>PlistPath</key>
    <string>Contents/Info.plist</string>
</dict>
   <key>Arch</key>
    <string>x86_64</string>
    <key>BundlePath</key>
    <string>IntelBTPatcher.kext</string>
    <key>Comment</key>
    <string>A Lilu base patcher that fix Intel Bluetooth</string>
    <key>Enabled</key>
   <true/>
   <false/>
   <key>ExecutablePath</key>
    <string>Contents/MacOS/IntelBTPatcher</string>
   <key>MaxKernel</key>
    <string></string>
    <key>MinKernel</key>
    <string>16.0.0</string>
    <key>PlistPath</key>
    <string>Contents/Info.plist</string>
</dict>
    <key>Arch</key>
    <string>x86 64</string>
    <key>BundlePath</key>
    <string>IntelBluetoothFirmware.kext</string>
    <key>Comment</key>
    <string>Bluetooth</string>
   <key>Enabled</key>
   <true/>
  <false/>
   <key>ExecutablePath</key>
    <string>Contents/MacOS/IntelBluetoothFirmware</string>
    <key>MaxKernel</key>
    <string></string>
    <key>MinKernel</key>
    <string>16.0.0</string>
    <key>PlistPath</key>
    <string>Contents/Info.plist</string>
```

```
</dict>
    <key>Arch</key>
    <string>x86_64</string>
    <key>BundlePath</key>
    <string>IntelBluetoothInjector.kext</string>
    <key>Comment</key>
    <string>Bluetooth</string>
    <key>Enabled</key>
    <true/>
   <false/>
   <key>ExecutablePath</key>
    <string></string>
   <key>MaxKernel</key>
   <string>20.99.99</string>
    <key>MinKernel</key>
    <string>16.0.0</string>
    <key>PlistPath</key>
    <string>Contents/Info.plist</string>
</dict>
```

• Also, add these code into Kernel - Add section: (Don't need to do this step if you just want to disable the embedded Intel Bluetooth)

```
<dict>
    <key>Arch</key>
    <string>x86_64</string>
    <key>BundlePath</key>
    <string>BrcmBluetoothInjector.kext</string>
    <key>Comment</key>
    <string></string>
    <key>Enabled</key>
    <true/>
    <key>ExecutablePath</key>
    <string></string>
    <key>MaxKernel</key>
    <string>20.99.99</string>
    <key>MinKernel</key>
    <string>14.0.0</string>
    <key>PlistPath</key>
    <string>Contents/Info.plist</string>
</dict>
<dict>
    <key>Arch</key>
    <string>x86_64</string>
    <key>BundlePath</key>
    <string>BrcmFirmwareData.kext</string>
    <key>Comment</key>
    <string></string>
    <key>Enabled</key>
    <true/>
    <key>ExecutablePath</key>
    <string>Contents/MacOS/BrcmFirmwareData</string>
    <key>MaxKernel</key>
```

```
<string></string>
    <key>MinKernel</key>
    <string>14.0.0</string>
    <key>PlistPath</key>
    <string>Contents/Info.plist</string>
<dict>
    <key>Arch</key>
    <string>x86 64</string>
    <key>BundlePath</key>
    <string>BrcmPatchRAM3.kext</string>
    <key>Comment</key>
    <string></string>
    <key>Enabled</key>
    <true/>
    <key>ExecutablePath</key>
    <string>Contents/MacOS/BrcmPatchRAM3</string>
    <key>MaxKernel</key>
    <string></string>
    <key>MinKernel</key>
    <string>19.0.0</string>
    <key>PlistPath</key>
    <string>Contents/Info.plist</string>
</dict>
```

• For macOS12, re-enable BlueToolFixup is necessary: (Don't need to do this step if you just want to disable the embedded Intel Bluetooth)

```
<key>Arch</key>
   <string>x86 64</string>
   <key>BundlePath</key>
   <string>BlueToolFixup.kext</string>
   <key>Comment</key>
   <string>Force BlueTool to skip firmware update on Monterey</string>
   <key>Enabled</key>
   <true/>
   <key>ExecutablePath</key>
   <string>Contents/MacOS/BlueToolFixup</string>
   <key>MaxKernel</key>
   <string></string>
   <key>MinKernel</key>
   <string>21.0.0</string>
   <key>PlistPath</key>
   <string>Contents/Info.plist</string>
</dict>
```

Solder D+ and D- wires to the WLAN_LTE slot (TM1701 Only)

- Buy and insert a supported internal wireless card(e.g. BCM943602CS) in M.2 slot
- Carefully solder D+ and D- wires to the WLAN LTE slot as #7
- Go to Windows, run Device Manager to check whether the soldering is success or not

- For Clover users:
 - If success, replace /CLOVER/ACPI/patched/SSDT-USB.aml with SSDT-USB-WLAN LTEBT.aml
 - Delete BlueToolFixup.kext,IntelBTPatcher.kext, IntelBluetoothFirmware.kext, and IntelBluetoothInjector.kext in /CLOVER/kexts/
- For OC users:
 - Add SSDT-USB-WLAN_LTEBT.aml to /OC/ACPI/
 - Open /OC/config.plist, change the following code:

• And then change the following code:

• Don't forget to disable Intel Bluetooth kexts, change the following code:

```
<key>Arch</key>
    <string>x86 64</string>
    <key>BundlePath</key>
    <string>BlueToolFixup.kext</string>
    <key>Comment</key>
    <string>Force BlueTool to skip firmware update on Monterey</string>
    <key>Enabled</key>
   <true/>
   <false/>
   <key>ExecutablePath</key>
   <string>Contents/MacOS/BlueToolFixup</string>
   <key>MaxKernel</key>
    <string></string>
   <key>MinKernel</key>
    <string>21.0.0</string>
    <key>PlistPath
    <string>Contents/Info.plist</string>
</dict>
    <key>Arch</key>
    <string>x86 64</string>
    <key>BundlePath</key>
    <string>IntelBTPatcher.kext</string>
```

```
<key>Comment</key>
    <string>A Lilu base patcher that fix Intel Bluetooth/string>
    <key>Enabled</key>
   <true/>
  <false/>
   <key>ExecutablePath</key>
   <string>Contents/MacOS/IntelBTPatcher</string>
    <key>MaxKernel</key>
    <string></string>
    <key>MinKernel</key>
    <string>16.0.0</string>
    <key>PlistPath</key>
    <string>Contents/Info.plist</string>
</dict>
    <key>Arch</key>
    <string>x86_64</string>
    <key>BundlePath</key>
    <string>IntelBluetoothFirmware.kext</string>
    <key>Comment</key>
    <string>Bluetooth</string>
   <key>Enabled</key>
   <true/>
  <false/>
   <key>ExecutablePath</key>
   <string>Contents/MacOS/IntelBluetoothFirmware</string>
    <key>MaxKernel</key>
    <string></string>
    <key>MinKernel</key>
    <string>16.0.0</string>
    <key>PlistPath</key>
    <string>Contents/Info.plist</string>
</dict>
    <key>Arch</key>
    <string>x86_64</string>
    <key>BundlePath</key>
    <string>IntelBluetoothInjector.kext</string>
    <key>Comment</key>
    <string>Bluetooth</string>
   <key>Enabled</key>
   <true/>
  <false/>
   <key>ExecutablePath</key>
   <string></string>
   <key>MaxKernel</key>
    <string>20.99.99</string>
    <key>MinKernel</key>
    <string>16.0.0</string>
    <key>PlistPath</key>
    <string>Contents/Info.plist</string>
</dict>
```

Solder D+ and D- wires to the fingerprint slot

- Buy and insert a supported internal wireless card(e.g. BCM943602CS) in M.2 slot
- \bullet Carefully solder D+ and D- wires to the fingerprint slot as #246
- Go to Windows, run Device Manager to check whether the soldering is success or not
- For Clover users:
 - If success, replace /CLOVER/ACPI/patched/SSDT-USB.aml with SSDT-USB-FingerBT.aml
 - Delete BlueToolFixup.kext,IntelBTPatcher.kext, IntelBluetoothFirmware.kext, and IntelBluetoothInjector.kext in /CLOVER/kexts/
- For OC users:
 - Add SSDT-USB-FingerBT.aml to /OC/ACPI/
 - Open /OC/config.plist, change the following code:

• And then change the following code (If you can't find it, please add manually):

• Don't forget to disable Intel Bluetooth kexts, change the following code:

```
<key>Arch</key>
   <string>x86_64</string>
   <key>BundlePath</key>
   <string>BlueToolFixup.kext</string>
   <key>Comment</key>
   <string>Force BlueTool to skip firmware update on Monterey</string>
   <key>Enabled</key>
   <true/>
   <false/>
   <key>ExecutablePath</key>
   <string>Contents/MacOS/BlueToolFixup</string>
   <key>MaxKernel</key>
   <string></string>
   <key>MinKernel</key>
   <string>21.0.0</string>
   <key>PlistPath</key>
   <string>Contents/Info.plist</string>
</dict>
```

```
<key>Arch</key>
    <string>x86 64</string>
    <key>BundlePath
    <string>IntelBTPatcher.kext</string>
    <key>Comment</key>
    <string>A Lilu base patcher that fix Intel Bluetooth/string>
    <key>Enabled</key>
   <true/>
   <false/>
    <key>ExecutablePath</key>
    <string>Contents/MacOS/IntelBTPatcher</string>
    <key>MaxKernel</key>
    <string></string>
    <key>MinKernel</key>
    <string>16.0.0</string>
    <key>PlistPath</key>
    <string>Contents/Info.plist</string>
</dict>
    <key>Arch</key>
    <string>x86_64</string>
    <key>BundlePath</key>
    <string>IntelBluetoothFirmware.kext</string>
    <key>Comment</key>
    <string>Bluetooth</string>
   <key>Enabled</key>
   <true/>
  <false/>
   <key>ExecutablePath</key>
   <string>Contents/MacOS/IntelBluetoothFirmware</string>
    <key>MaxKernel</key>
    <string></string>
    <key>MinKernel</key>
    <string>16.0.0</string>
    <key>PlistPath</key>
    <string>Contents/Info.plist</string>
</dict>
    <key>Arch</key>
    <string>x86 64</string>
    <key>BundlePath</key>
    <string>IntelBluetoothInjector.kext</string>
    <key>Comment</key>
    <string>Bluetooth</string>
   <key>Enabled</key>
   <true/>
   <false/>
   <key>ExecutablePath</key>
   <string></string>
    <key>MaxKernel</key>
    <string>20.99.99</string>
    <key>MinKernel</key>
    <string>16.0.0</string>
```

<key>PlistPath</key>
 <string>Contents/Info.plist</string>
</dict>