


User manual of Thermo-hygrometer

◆ Product diagram



◆ Operation Method



1. In the power-off state, short press the key to turn on;
2. In the power-on state, short press the key to switch the temperature unit to $^{\circ}\text{C}$ (Celsius) $^{\circ}\text{F}$ (Fahrenheit);
3. In the power-on state, press and hold the key for 3 seconds to power off.

◆ Product specifications

Temperature measurement range: $-50^{\circ}\text{C} \sim +70^{\circ}\text{C}$ ($-58^{\circ}\text{F} \sim +158^{\circ}\text{F}$)

Temperature measurement accuracy: $\pm 1^{\circ}\text{C}$ (1.8°F)

Temperature resolution: 0.1°C (0.2°F)

Humidity measurement range: 10%RH-99%RH

Humidity measurement accuracy: $\pm 5\%\text{RH}$

Humidity resolution: 1%

Power supply: CR2032*1

◆ Basic functions

Power on/off function

$^{\circ}\text{C}/^{\circ}\text{F}$ switch display

temperature display

Humidity display

Comfort indicator

◆ Description of comfort level

Humidity display between 10%-39% : 😊 ;

Humidity display between 40%-70% : 😊 ;

Humidity display between 71%-99% : 😊 .