

Inprocess Inspection - SOP

Titan Track and Trace

1.Login

- Login to the application using your credentials.

2.Navigate to Inprocess Inspection

- From the left navigation menu, click **Inprocess Inspection**.
- The Inprocess Inspection Pick Table is displayed.
- The Pick Table shows all submitted Jig Loading records that are ready for inspection.

3.Select the Jig

- Locate the required Jig in the Pick Table.
- Review the jig details before starting the inspection.

4.Select the Bath Number

- Choose the appropriate Bath Number from the Bath Number dropdown.
- Once a valid Bath Number is selected, the Inspection hyperlink/button becomes enabled.

The inspection process cannot begin until a Bath Number is selected.

5.Click Inspection

- Click the Inspection hyperlink/button for the selected jig.
- The Inspection window opens.

Inspection Process

Step 6 - Select Jig Position

- Select the appropriate Jig Position from the available positions.
- Ensure the selected position correctly represents the physical jig location.

Step 7 - Enter Remarks (Optional)

- If required, enter inspection remarks.
- Remarks are optional and can be used to record any observations made during inspection.

Step 8 - Submit

- Verify the selected Bath Number and Jig Position.
- Click Submit to complete the Inprocess Inspection.

Completion Flow

- After successful submission, the Jig is marked as **Inprocess Inspection Completed**.
- The selected Jig Position and optional remarks are saved for the processed jig.