## How to Change Analog Values to Real values.

## Temperature Range 0-70 Degree Celsius, Relative Humidity Range: 0-100%

Eg. Voltage value of temperature sensor to Real Temperature Value. Voltage Range was 0-10 Volts

- Temperature = Voltage \* 7
- Relative Humidity = Voltage \* 10

| Voltage | Temperature | Relative Humidity |
|---------|-------------|-------------------|
| 0       | 0           | 0                 |
| 0.5     | 3.5         | 5                 |
| 1       | 7           | 10                |











