

Startup

Clear robot-held state. Preserve CNC/TI WIP.

Start Async

A_FSTART owns feeder.
A_CSTART owns conveyor.

Main Loop

Run only eligible station phases.

CNC Exchange

Unload/load CNC when F61 or F62 has work.

TI Exchange

Move part through insertion workflow.

Place Conveyor

Release print part, then start conveyor.

Finish Work?

yes

Go Home

End at reviewed home/perch.

fault

Alarm/Recovery

Bounded waits raise UALM and preserve WIP.

continue