Product: HTR-927

Application Instructions:

1. **Prepare the Surfaces:** Before applying the adhesive, agitate the adhesive thoroughly to ensure consistency. Substrates should be clean and free of moisture, dirt, oil, and other contaminants. For best results, allow both the adhesive and the substrates to acclimate to room temperature, ideally 60°F or above, before beginning application. Additionally, the container itself should be at room temperature, between 65°F and 70°F, before use.

2. **Apply the Adhesive:** Apply a minimum of 2.0 to 2.5 dry grams per square foot. On porous surfaces, including CARB2 particleboard, two coats work best: a base coat followed by a top coat, with the second coat allowed to dry completely before assembly. Adhesive should cover at least 80% of the substrate's surface, and once fully dry, the coated surface should have a uniform glossy sheen. Dull areas indicate insufficient coverage and should be re-coated.

3. **Coat the Edges and Corners:** All exposed edges and corners should receive two coats of adhesive, just like the main surface.

4. **Check for Dryness:** Letting the adhesive dry completely before assembly is essential for a secure, permanent bond. To check, press a piece of kraft paper onto the adhesive surface: if adhesive transfers to the paper, it needs more time to dry; if nothing transfers, the substrates are ready to bond.

5. **Address Problem Areas:** If an area has excessive adhesive buildup, press it with gloved fingers and twist to break up any film that has formed as the surface dries. If a skin has already formed, allow extra time for the solvent underneath to fully evaporate before bonding.

6. **Speed Up Drying (Optional):** Dry times can be shortened using air movement, drying ovens, lamps, or similar methods.

7. **Bond the Substrates:** Once dry, bring the substrates together within 30 minutes (open time). Position carefully, since the bond is instant and can't be repositioned.

8. **Apply Pressure:** Uniform pressure across the bonded laminates is necessary for a strong, lasting bond. A pressure of 40 pounds per linear inch is recommended to ensure complete fusion between the two adhesive layers. A pinch roller is ideal for this, though a properly used J-roller can also provide adequate pressure.

9. **Finish:** Once bonded, the assembly can be immediately routed, trimmed, cut, filed, and machined.