TORQUE PROCEDURE TP-204
Acme Manufacturing - Controlled Document
Document Number: TP-204
Revision: B
CAGE Code: 1ABC3

1 PURPOSE

This procedure defines the bolt torque sequence for the main flange assembly.

2 SAFETY PRECAUTIONS

WARNING

The line must be depressurised before any fastener is loosened.

2.1 Lockout and tagout

Isolate the supply valve and apply a personal lock.

2.2 Residual pressure check
Open the bleed port and confirm zero reading on the gauge.
CAUTION:
Fluid may be hot.

3 TORQUE SEQUENCE

Tighten the fasteners in a star pattern in three stages.

3.1 Stage one - 30 Nm

Apply 30 Nm to each fastener in the sequence shown.

3.2 Stage two - 60 Nm
Apply 60 Nm in the same order.
APPENDIX A
Calibration records are retained for seven years.