

2. LIMITATIONS


2.1 SYSTEM LIMITS

The fuel system cold weather operation requirement that the fuel must contain an anti-icing additive when operating below +4 °C is no longer applicable.

3. EMERGENCY AND MALFUNCTION PROCEDURES

3.1 WARNING LIGHT INDICATIONS

WARNING LIGHT INDICATIONS



Conditions/Indications

Clogging of engine fuel filter and/or microfilter (affected engine) has begun

- **FILT** warning light (affected engine) on

Procedure

No change in the basic Flight Manual procedure.

3.2 SUPPLY TANK FUEL PUMP FAILURE

Conditions/Indications

Affected engine:

- Fuel pressure indication below 0.6 kp/cm²

Procedure

1. FUEL PUMPS/SUPPLY TANK switch – Off
(affected engine)
2. Altitude – As noted below or less

NOTE

- Max altitude when operating on MIL-T-5624, grade JP-5 or ASTM D-1655 Jet A and Jet A1 14,200 ft
- Max altitude when operating on MIL-T-5624, grade JP-4; MIL-T-83133, grade JP-8; ASTM D-1655 Jet B; or alternate fuel (AVGAS/Jet fuel mixture) 8,000 ft

3. Bank angles above 45° and abrupt maneuvers – Avoid

4. LAND AS SOON AS PRACTICABLE