





 PT. MNA SERANG	WORKING INSTRUCTION Low Output or High Output Flow Transmitter	WI/MNASRG-E&I-19-102	
		Dept.	ENGINEERING
		Section	E&I
		Revision	0
		Effective Date	
		Page	1 of 1 page

Instruksi / <i>Instruction</i>	
Persiapan Alignment / <i>Prepare of Alignment Process</i>	
	
Siapkan peralatan dan APD (<i>Prepare equipment and APD</i>)	Identification: Pembacaan rendah atau tinggi (<i>Low Or High Output</i>)
Pengecekan Elemen Sensor/ <i>Sensor Element Checking</i>	
	
Cek variable tekanan yang sesuai dengan standard saturasi (<i>Check pressure variable reading for saturation</i>)	Cek jika ada keluaran berupa alarm (<i>Check if output is in alarm condition</i>)
Loop Wiring Test	
	
Periksa sinyal masukan 4-20mA (<i>Checking Perform 4-20 mA output trim</i>)	Reset pada bagian Totalizer (<i>Reset the Totalizer</i>)
Eelectronic Module Check	
	
Koneksikan Field Communicator dan lakukan pengaturan kalibrasi (<i>Connect a Field Communicator calibration adjustments</i>)	Jika masih belum berfungsi, Ganti papan electronic (<i>Replace electronics board</i>)