

First step:
Inform the workshop operation content, inform the operation purpose, and sign the work ticket.



Second step: Prepare a Fluke 1623-2 Earth/Ground Tester, an Electrical Integrity Check Sticker, and a Tools for helping us open the Groduning pit cover.



Third step: Open the grounding pit cover and clean it from the dirt



Fourth step: Set & connect all of the Clamp's cable to the Fluke 1623-2 and set the selector switch to the picture of two clamps.



Fifth step: Set the sensing clamp on the BC which is connected and closest to the rod with the arrow pointing to the ground



The sixth step: : Set the inducing clamp 10 cm before the sensing clamp on the same BC and the same direction of the arrow



Seventh step: Press the start button and take the measurement 3 times. Take a photo of the measurement result of each measurement



Eighth step: Collect the data by writing the results of the resistance readings on each test on the form F/MNASRG-E&I-20-116

WILMAR		EARTH TESTER									
PT MNASRG											
Date		2021									
Time		00:00									
No	Locality	Locality Type	Locality	Locality Date	Measurement Result	Result	Test Date	Test Time	Test Time	Test Time	Result
1	00000000000000000000	Power Supply	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000
2	00000000000000000000	Power Supply	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000
3	00000000000000000000	Power Supply	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000
4	00000000000000000000	Power Supply	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000
5	00000000000000000000	Power Supply	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000
6	00000000000000000000	Power Supply	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000
7	00000000000000000000	Power Supply	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000
8	00000000000000000000	Power Supply	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000
9	00000000000000000000	Power Supply	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000
10	00000000000000000000	Power Supply	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000	00000000000000000000

Nineth step: Install the green electrical integrity if the resistance value matches the standard and red if doesn't match the standard

