

TSIMHM5A Red Rice Mobile Phone 5A Series I and II Maintenance Guide V01

- TSIMHM5A Red Rice Mobile Phone 5A Series I and II Maintenance Guidance V01 I. Precautions for Fault Entry
- Second, maintenance guidance
 - [1](#). Switching failure
 - [1.1](#) Do not boot MPFUN0101
 - STEP 2 Show malfunction
 - 2.1 Display striped or underlined MPFUN0405
 - 3. SIM Cato fault
 - 3.1 SIM Cato cannot plug MPCOM2202
 - 4. Camera failure
 - 4.1 Camera cannot open MPFUN 1901
 - 5. Speaker failure
 - 5.1 Non-talk Speaker Noise MPFUN0501

I. Precautions for Fault Entry

- Touch screen appearance fault refers to the appearance of the touch screen when the screen is extinguished, such as bubbles, breakage, different colors and other undesirable phenomena. Do not display the fault inside the different color points, color spots, light leakage and other bad phenomena that can only be seen after lighting the screen into the touch screen appearance bad fault inside.
- Bad appearance fault of battery cover refers to abnormal sound, different color, paint drop, damage and other bad phenomena of battery cover. Do not enter GAP problem (the gap between battery cover and front shell exceeds the standard) into this bad item, and pay attention to distinguish it from bad appearance fault of back shell, which refers to the internal structural parts of mobile phone.
- Bad appearance of the front shell refers to the bad phenomena such as different colors, paint falling and damage in the front panel of the mobile phone except the display screen. Note that the poor appearance of the middle frame (paint drop, paint crack, deformation, etc.) should be entered into the corresponding fault items of the poor appearance of the front shell.

Second, maintenance guidance

1. Switching failure

1.1 Do not boot MPFUN0101



STEP 2 Show malfunction

2.1 Display striped or underlined MPFUN0405



3. SIM Cato fault

3.1 SIM Cato cannot plug MPCOM2202

确认故障现象

故障现象为：SIM卡槽PIN脚破损、SIM卡托无法插拔（确保SIM卡托有字一面朝上，切不可反插SIM卡托）



维修思路

维修方法：

1.拆机检查SIM卡槽结构和尺寸，排除SIM卡槽和卡座问题。



其他问题
分析解决

2.交叉验证试验：101更换主板。

4. Camera failure

4.1 Camera cannot open MPFUN 1901

确认故障现象

故障现象为：后置相机无法打开



维修思路

维修方法：
1. 拆机后检查后置摄像头模组BTB连接器，排除组装问题。
系统维修方法选择：407清洁/调整重装

BTB未扣合到位



其他问题
分析解决

2. 交叉验证试验：更换后置摄像头和主板，确认故障点排除故障。
系统维修方法选择：111更换摄像头、101更换主板

5. Speaker failure

5.1 Non-talk Speaker Noise MPFUN0501

确认故障现象

故障现象为：非通话状态扬声器杂音

维修思路

维修方法：

1.拆机检查扬声器外观完好，排除压痕、压伤等情况的出现。

系统维修方法选择：107更换扬声器喇叭



其他问题
分析解决