

SAFETY FIRST

Isolate the circuit, verify absence of voltage, support the busbar and use suitable PPE.

Qualified personnel only

STEP 01

ALIGNMENT



ALIGN THE ELEMENT ENDS

Bring the joining surfaces together. Keep both sections level and align the connection slot before fastening.

CHECK: Ends level and slot aligned



STEP 02

M4 + JOINT SET



FIT AND SECURE THE JOINT

Secure the connection with the M4 screw, then position the GNL joint set correctly over the joined elements.

CHECK: Joint set fully seated



STEP 03

4 x M5x15 / IP55



CLOSE THE JOINT COVER

Fit the cover with 4 x M5x15 screws. Ensure it is fully seated to restore IP55 and mechanical protection.

CHECK: Cover flush with no visible gap



FINAL VERIFICATION



Elements are aligned and mechanically supported.



M4 fixing, joint set and all 4 cover screws are installed.



Cover is flush; no visible gap, damage or trapped material.