## The following article is Inspired by the work of LA8OKA MARTIN

### Original reference on:

http://www.arcticpeak.com/radiopages/kenwood\_ts-2000\_12\_khz\_if\_output.htm


#### WARNING!

Do not try this if you don't have experience on soldering small parts. Use only a soldering iron of max 30W.

### Be prepared with:

- -Soldering iron 30W;
- -Hot glue;
- -Double sided adhesive tape;
- -1 m of shielded audio cable;
- Philipps Screw-driver
- -Clams.

1. LOCALIZATION OF WORKING SECTOR
Carefully remove the panels of the radio.
Place the radio with the upside down and the front to you.




IF output for Kenwood TS 2000 X transceiver.



## 2. PLACE A DOUBLE ADHESIVE TAPE. Leave the pprotection foil on the tape.



# 2. PREPARE THE PIGTAIL CABLE. I decided to use a small stereo 3.5 mm female headphone connector.





## 3. USE THE RCA CONNECTOR TO ROUTE OUTSIDE THE PIGTAIL CABLE

It's hard to find a opening to route the cable outside from the radio. I use the inner hole of the receiving HF antenna RCA.






### 4. SOME RE-ROUTING WORK WITH THE CABLES INSIDE THE RADIO.

I do some re-routing work on the cables because it looks to me that the cables put some mechanical stress on the radio components.

I used a few tyre-up's for this work It is not necessary.



5. MECHANICAL FIXING THE CABLE WITH SOME HOT GLUE. I fix the cable with hot glue.





6. PLACE THE CAPACITOR (0.1 microF) AS SHOWN, ON THE DOUBLE ADHESIVE TAPE.

But first, you have to do some preparations as shown.




IF output for Kenwood TS 2000 X transceiver.



8. REMOVE THE SCREW, SOLDER THE GROUND OF THE PIGTAIL CABLE. CAREFUL NOT TO MELT THE CAPACITOR AND THE BOARD CONNECTOR.



### 9. SOLDER THE PIGTAIL CENTER CABLE ON THE CAPACITOR.



10. SOME MECHANICAL FIXING OF THE PIGTAIL CABLE WITH HOT GLUE.



Article by YO3HJV, Adrian. The reproduction of this article is permitted only if is not altered.

### 11. RECEIVE WHATEVER YOU WANT!

