- 1. This device compiles with Part 15 of the FOC Rules. Operation is subject to the following was conditions are sharrful interference. This device may not cause harmful interference received, including interference that (2) This device must accept any interference received, including interference that
- (v.) innovancia tunis a capita printerenore received, including interference that may cause undesired operation.

 They cause undesired operation.

 Compliance could void the best's authority to operate the equipment.

 Compliance could void the best's authority to operate the equipment.

 On This equipment has been sessed and found to comply with the limits for a class 8 digital device, pursuant to Part 1's of the FCC Rules. These timits are designed to prode reasonable protection against hamful interference in a residential installation.

 This equipment generates uses and can radiate radio frequency energy and, if not installed and
- used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in is particular installation. If this equipment does cause harmful interference to radio for television reception, which can be determined by furning the equipment off and mut the user is encouraged to try to correct the interference by one or more of the following measures.
 - ient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - FR exposure information: The EIPS power of the double at maximal case is below the event condition, 20MW specified in EVE2479, 2010.

 RF exposure assessment has been parformed to prove that this unit will not exposure assessment that the first open to prove that this unit will not be considered the harmful EV emission before the reference level as specified in EC Council Recommendation (1990/6) (9EC). Consult the dealer or an experienced radio/TV technician for help. The device has been evaluated to meet general RF exposure requirem:
- This equipment comples with FCC RF radiation exposure limits set forth for an uncontrolled environment.
- This equipment complex with FCC radiation exposure limits set forth for an unroundfed environment. This equipment should be restalled and operated with minimum distance of 20 on between the radiation and you body. This wasternier must be co-obcasted or operating in conjunction with any other antenior of the co-obcasted or operating in conjunction with any other antenior of the co-obcasted or operating in conjunction with any other antenior.

www.amobilepayment.com

General Precautions

Basic care and consideration should be used when handling, operating or installing the 6500 terminal. This is a secure device, with both physical and logical tamper protection, and no attempt should be made by the user to open or service the device in any way other than approved troubleshooting methods. Keep these basic guidelines in mind to prolong the ongevity and functionality of your product:

 With the exposed chip facing downward, and the angled corner oriented away from the slot, insert the card until it is seated right at the bottom of the slot Ensure that any installed cards are securely locked in place, and close the rear cover

Open the rear cover to reveal the card slots

Installation of a SIM/SAM/TF card

- Do not use the non-dedicated power supply, because it may be in trouble due to the mismatch of power.
 - Do not vibrate, shake or knock the product sharply.
- When a fault occurs, immediately turn off the power supply and dis-
 - Do not open and repair if by yourself.
- When the terminal being attacked by unscrupulous environment(such as opening the terminal shell, etc.), the internal sensitive information stored in the terminal will be erased. For avoiding unnecessary trouble, you should not open the housing.
- AMP 6500 is designed to be unatte
- . The device should be covered by a pin shield over the pin entry area.
- Avoiding the direct sunlight and the rain.
 Place the device in a ventilated locality and I

Powering Device On/Off

First ensure that the plug is inserted into a known working socket, then insert the Microfi Powering On the device

Powering Off the device

Unplug the DC Jack from the back of the terminal and it will power itself Off.

Advanced Mobile Payment Inc.

www.amobilepayment.com

9

DOCUMENT PROPERTIES

CONTENTS

Information

2	PUR-6500-1.0-€
Title	Quick Reference Guide
Category	AMP POS 6 Series - 6500
Acres I med	Conora

Back & Side View AMP 6500 Architecture

2.3

Front View Ports General Precautions

Version Control

sq pa

Troubleshooting Common Problems Installing SIM/SAM Card Powering Device On/Off.

Supported Hardware & Software

Supported Hardware Model	AMP 6500+CB	
Software Release	1.0	
Version	1.0+	

Advanced Mobile Payment Inc.

www.amobilepayment.com

Advanced Mobile Payment Inc.

Product Quick Reference Guids The AMP 6500 POS terminal

The Microfit cable

www.amobilepayment.com

The following items should be found inside the original packaging:

Troubleshooting Common Problems

Installing SIM/SAM/TF Card

If problems occur with the terminal, by these simple troubleshooting methods to correct the fault, or contact a service representative to further diagnose the Issue.

The following are specifications detailing the overall capabilities of the AMP 6500, including optional or variable elements. To obtain the specifications for your individual terminals, refer

Technical Specifications

to the original sales order or your sales representative for more information.

Troubleshooting	Ensure the power is properly connected at the socket and DC Jack	Ensure that the statis free of debris or foreign objects. Swipe the card in both directions, and check if ency has been corrected. Object if the current card is operational, and test with a different card.	Swipe the cond with constant speed, tight to the bottom edge of the stat. Ensure the coard strip is facing the screen and aligned properly with the stor. Try swiping the coard in the opposite direction.	Ensure the chity portion is facing upwards, and is properly inserted into the slot. Check the card for excessive scratches, dirt, or other damage.	Confirm that the card supports contactless communication Check whether the card is properly aligned above the contactless reader area	Restart the termined in order to re-establish communications Confirm that the SIM card is properly insistled, and that its contacts are clean If using Wift, check that the terminal's connection is enabled
Problem	Nothing displayed	Unable to	Magnetic reader	Chip card	Contactless card	Communication
	on screen	read card	data read error	data read error	data read error	error

If problems persist offer completing these troubleshooting procedures, please contact your sales or service representative, but and afforting to open the terminal or make there requires. CAUTION 1884 OF FEV. DESON # FEATTER'N S REPUACED BY AN INCORRECT TIPPE DISPOSE OF USED BATTERES. ACCORDING TO THE INSTRUCTIONS.

Hereby, Advanced Mobile Payment Inc. declares that the radio equiptment type [AMP 6500]

The full text of the EU Declaration of Conformity is available on our

is in compliance with Directive 2014/53/EU

Regulatory Conformance

WATERPROOF

-20°C ~ 45°C(-4°F ~ 113°F), 10% ~ 90% (non-condense)

PHYSICAL BUTTONS SYSTEM WEIGHT





Votice: This device may be used in each member state in EU

www.amobilepayment.com

Advanced Mobile Payment Inc.

www.amobilepayment.com

Advanced Mobile Payment Inc.

www.amobilepayment.com

Back View 2.2

SIM/SAM card cover

capture, chip and PIN, NFC/contactless, smartphone payments, electronic wallets and tap-and-go compatibility. The Android OS and 4 core secure processor provide power and

simple application development options to meet the most demanding needs of any multi-fane or self-checkout environment. Optimized for the next generation of value-added services, gift card issuing and support of loyalty schemes, the AMP 6500 is the ultimate

choice for a complete multimedia transaction solution.

AMP 6500 Architecture

Front View

Engage customers in new ways with the AMP 6500's crystal clear 5" color touch display and video capabilities, all while accepting payment options that appeal to them with signature

Introduction

Menu for setup

5 Tag label Reset

> စု စုခု φ

> > Ports 23



Antenna inductive zone

User smart card slot Waterproof ring

9

0

Magnetic stripe card

4 Infrared sensor

9

9 9

NFC leds Camera

Ø

⊙— **⊙**— **⊙**—

2 USB-device USB-host

RS232 5 Audio e MDB

4 Ethernet

စုစု စု

www.amobilepayment.com

Advanced Mobile Payment Inc.

Advanced Mobile Payment Inc.

www.amobilepayment.com

GIUI

AMP 6500

Quick Reference Guide

PQR-6500-1.0-E

PCI PTS S.X, EMV LEVEL 18.2, EMV Contactlets, CE, FCC, Pay Pass Bi-directional triple-track magstripe reader, landed smart card, NPC, 13.56MH

RS-232, Ethernet 10/100M, MDB

CONNECTIVITY CARD READERS

RAM, BGB Flash memory, Support Micro TF Card, up to 32GB

High Performance 4 Core Processor + Secure CPU

PROCESSOR

Advanced Mobile Payment Inc.

Units 401-403, 15 Wertheim Court. Richmond Hill, Ontario L4B 3H7 CANADA All pages of this document contain information proprietary to Advanced Mobile Payment fine (AMP). This document shall not be duplicated, transmitted, used, or otherwise disclosed to amyone other than the organization or specific individuals to which this document is delivered, and then only for the purpose of evaluation of the AMP proposal. This restriction is applicable to all sheers of this document. AMP reserves the right to have the recipient return all copies of this document as any time.

© 2017 AMP Inc. All Rights Reserved

Hitter Pranformation is COVIED VITIA on must be used exclassible from the coverning Advisored vitoble Remember (1972) and become substantly from the could also found that is on deaths of a Yang, and writing of mission.