

Corporate HSE PPE Standard

This corporate standard applies to all field technicians across every discipline. It covers personal protective equipment (PPE), high visibility clothing, working at height, and fatigue management.

1. Hand Protection (Glove Classes)

Select hand protection appropriate to the hazard. Insulating gloves must be class-rated for the working voltage and inspected before use.

Glove Class	Max Working Voltage	Typical Use
Class 00	500 V	Low voltage work
Class 0	1000 V	LV switching
Class 2	17000 V	HV up to 17 kV
Class 4	36000 V	HV up to 36 kV

2. High-Visibility Clothing

Wear high-visibility (hi-vis) clothing to at least class 2 on any site with vehicle or plant movement. Hi-vis must be clean and serviceable.

3. Working at Height

Working at height means any work above 2 m where a fall could cause injury. Use fall protection, a rated harness and edge protection. Inspect the harness before each use.

4. Fatigue Management

Do not work more than 12 hours in a shift without a documented risk assessment. Take a rest break at least every 2 hours. If you are too fatigued to work safely, stop work and contact your supervisor.