

CNC TRAY CAPTURE

one tool, about ninety seconds

1 SHEET

Take a fresh trace sheet from the stack. Write the tool's TAG (T0__, from the drawer label) in the TAG box.

2 HEIGHT

Slide the tool edge-on into the gauge. The smallest slot it enters is its height: 10, 20, 30, 40 or 50. Write it in the HEIGHT box.

3 LAY

Lay the tool inside the field, as it sits in the drawer. Clear of the border line and of the four corner squares.

4 TRACE

Pencil in the TRACE collar. Straight up like a candle, collar riding the tool. Trace the OUTSIDE only, all the way round, until the line meets itself.

5 PHOTO

Lift the tool off. Photograph the whole sheet from above: all four corner squares in frame, sheet flat, no shadow across the line.

6 FORM

Open the form “CNC tray capture”: tag, height, photo. Done. The tray regenerates; a rejected sheet comes back with one line saying why.

One tool per sheet. Never a hand in the field, never a tool on its edge, never a tool that moved.

Sheets, collar, pencil and gauge live in Drawer 1. Print sheets at 100%: the bar at the bottom must measure 100mm.