HOORVIA - SLATE ENGRAVING TROUBLESHOOTING: PRINTABLE FIX GUIDE

Quick Reference Cheat Sheet · A4 Printable

Crafting & DIY · Sheet #1

Problem	Cause	Fix	Prevent
Engraving too faint	Pressure too low	Increase pressure	Test on a scrap slate
Engraving too deep	Pressure too high	Reduce pressure	Start at medium
Slate cracks	Too much pressure	Lower pressure, use a mat	Use the right slate thickness
Design shifts	Slate not secured	Tape the slate down	Use painter's tape
Engraving skips	Debris on the slate	Clean the slate	Wipe before engraving
Lines look rough	Wrong tool	Use the engraving tip	Check the tip is seated
Slate chips at edges	Mat too thin	Use a strong-grip mat	Support the slate fully
Design misaligned	Wrong mat size	Use the right mat	Preview in Design Space
Engraving incomplete	Design too large	Resize to fit the slate	Measure the slate first
Slate moves mid-cut	Mat lost stickiness	Replace or clean the mat	Wash the mat with soap
Tool marks on the surface	Tip dragging	Check the tip	Replace a worn tip
Slate breaks in the machine	Slate too thick	Use 2mm or thinner slate	Check the machine's limit

PRO TIP: Test on a scrap slate first: Every slate is a different thickness and hardness. Engrave a scrap with your exact settings before you touch the real piece.