

```
(BEGIN CUTTING BLOCKS) ;  
G249 X2.1 Y0.125 Z-1.3 C35. R4. P1.35 F20. ;  
(Bore to X2.1) ;  
X1.85 Y-0.255 Z-0.865 C-75. P1.65 (next position) ;  
(BEGIN COMPLETION BLOCKS) ;  
G00 Z1. M09 (Rapid retract, Coolant off) ;  
M155 (Disengage C Axis) ;  
M135 (Live tool off) ;  
G53 X0 Y0 (X & Y home) ;  
G53 Z0 (Z home) ;  
M30 (End program) ;  
%
```

7.2 More Information Online

For updated and supplemental information, including tips, tricks, maintenance procedures, and more, visit the Haas Service page at www.HaasCNC.com. You can also scan the code below with your mobile device to go directly to the Haas Service page:



