

Листая доска (начало)

Цепи переменного тока (ЛЭ)			X
1	X 1	SG12	
2	X 2	SG14	
3	X 3	SG16	
4	X 4	SG18	
5	X 5	SG110	
6	X 6	SG112	
7			
8			
Цепи переменного напряжения			X
9	X 9	SG22	
10	X 10	SG24	
11	X 11	SG26	
12	X 12	SG28	
Цепи отбора напряжения			X
13	X 13	SG32	
14	X 14	SG34	
15	X 15	SG36	
Цепи оперативного тока			X
16	X 16	U211	
17	X 17	SG14	
18			
19			
20			
21			
22			
23	X 23	A1-M5.XB 1	
24			
25			
26	X 26	A1-M5.XB 3	
27			
28			
29	X 29	A1-M5.XB 5	
30			
31			
32			
33			
34			
35	X 35	A1-M5.XB 7	
36			
37	X 37	A1-M5.XB 9	
38	X 38	A1-M5.XB 11	
39			
40			
41			
42			
43			
44			

Листая доска (продолжение на листе 2)

Пробная доска (начало)

X	Выходные цепи		
A1-M2.XB 8	X 104	104	
A1-M2.XB 10	X 105	105	
A1-M2.XB 12	X 106	106	
A1-M2.XB 14	X 107	107	
A1-M2.XB 16	X 108	108	
A1-M2.XB 18	X 109	109	
A1-M2.XB 24	X 110	110	
A1-M2.XB 26	X 111	111	
A1-M2.XB 28	X 112	112	
A1-M2.XB 30	X 113	113	
A1-M2.XB 32	X 114	114	
A1-M3.XB 2	X 115	115	
SA5 9	X 116	116	
SA5 13	X 117	117	
SA5 17	X 118	118	
A1-M3.XB 4	X 119	119	
A1-M3.XB 6	X 120	120	
K2 1	X 121	121	
K2 2	X 122	122	
K2 5	X 123	123	
K3 1	X 124	124	
K2 9	X 125	125	
K2 10	X 126	126	
K2 14	X 127	127	
K3 9	X 128	128	
K3 10	X 129	129	
K3 14	X 130	130	
A1-M3.XB 8	X 131	131	
A1-M3.XB 10	X 132	132	
		133	
		134	
		135	
		136	
		137	
		138	
		139	
		140	
		141	
SA24	X 142	142	
SA26	X 143	143	
SA26	X 144	144	
SA28	X 145	145	
SA4 4	X 146	146	
SA4 6	X 147	147	
SA34	X 148	148	
SA36	X 149	149	
SA38	X 150	150	
SA3 10	X 151	151	
SA3 12	X 152	152	
SA26	X 153	153	

Пробная доска (продолжение на листе 2)

Условные обозначения

