

Левая боковина (начало)				
	Цепи переменного тока В1		X	
		1	X:1	SG1:2
		2	X:2	SG1:4
		3	X:3	SG1:6
		4	X:4	SG1:8
		5	X:5	SG1:10
		6	X:6	SG1:12
		7		
		8		
	Цепи переменного тока В2		X	
		9	X:7	SG2:2
		10	X:8	SG2:4
		11	X:9	SG2:6
		12	X:10	SG2:8
		13	X:11	SG2:10
		14	X:12	SG2:12
		15		
		16		
	Цепи переменного тока В3		X	
		17	X:17	SG3:2
		18	X:18	SG3:4
		19	X:19	SG3:6
		20	X:20	SG3:8
		21	X:21	SG3:10
		22	X:22	SG3:12
		23		
		24		
	Цепи переменного тока В4		X	
		25	X:25	SG4:2
		26	X:26	SG4:4
		27	X:27	SG4:6
		28	X:28	SG4:8
		29	X:29	SG4:10
		30	X:30	SG4:12
		31		
		32		
	Цепи переменного тока В5		X	
		33	X:33	SG5:2
		34	X:34	SG5:4
		35	X:35	SG5:6
		36	X:36	SG5:8
		37	X:37	SG5:10
		38	X:38	SG5:12
		39		
		40		

Левая боковина (продолжение на листе 2)

Условные обозначения

