

Левая боковина					
	Цепи переменного тока ШСВ/СВ			X	
		1	X:1	SG1:2	#
		2	X:2	SG1:4	
		3	X:3	SG1:6	
		4	X:4	SG1:8	
		5	X:5	SG1:10	
		6	X:6	SG1:12	
		7			
		8			
	Цепи напряжения рабочей 1 СШ			X	
		9	X:9	SG2:2	+
		10	X:10	SG2:4	
		11	X:11	SG2:6	
		12	X:12	SG2:8	
		13	X:13	SG3:2	
		14	X:14	SG3:4	
		15	X:15	SG3:6	
		16	X:16	SG3:8	
	Цепи напряжения 2 СШ			X	
		17	X:17	SG4:2	+
		18	X:18	SG4:4	
		19	X:19	SG4:6	
		20	X:20	SG4:8	
	Цепи оперативного тока			X	
		21	X:21	UZ1:1	+
		22	X:22	SG1:14	
		23	X:23	UZ1:4	+
		24	X:24	A1-M4.XB:2	
	Цепи сигнализации			X	
		25	X:25	A1-M1.XP:2	—
		26			
		27	X:27	HL1:2	—
		28			
	Освещение			X	
		29	X:29	SQ1:11	кч WE2
		30			
		31	X:31	SQ1:21	с
		32			

