

Левая доковина (начало)					
	Цепи переменного тока А1			X	
		1	X:1	SG1:2	#
		2	X:2	SG1:4	#
		3	X:3	SG1:6	#
		4	X:4	SG1:8	#
		5	X:5	SG1:10	#
		6	X:6	SG1:12	#
		7			
		8			
		9	X:9	SG2:2	#
		10	X:10	SG2:4	#
		11	X:11	SG2:6	#
		12	X:12	SG2:8	#
		13	X:13	SG2:10	#
		14	X:14	SG2:12	#
		15			
		16			
		17	X:17	SG3:2	#
		18	X:18	SG3:4	#
		19	X:19	SG3:6	#
		20	X:20	SG3:8	#
		21	X:21	SG3:10	#
		22	X:22	SG3:12	#
		23			
		24			
		25	X:25	SG4:2	#
		26	X:26	SG4:4	#
		27	X:27	SG4:6	#
		28	X:28	SG4:8	#
		29	X:29	SG4:10	#
		30	X:30	SG4:12	#
		31			
		32			
		33	X:33	SG5:2	#
		34	X:34	SG5:4	#
		35	X:35	SG5:6	#
		36	X:36	SG5:8	#
		37	X:37	SG5:10	#
		38	X:38	SG5:12	#
		39			
		40			
	Цепи переменного напряжения НН			X	
		41	X:41	SG6:2	+
		42	X:42	SG6:4	+
		43	X:43	SG6:6	+
		44	X:44	SG6:8	+
		45	X:45	SG6:10	+
		46	X:46	SG6:12	+
	Цепи переменного напряжения НН1			X	
		47	X:47	SG7:2	+
		48	X:48	SG7:4	+
		49	X:49	SG7:6	+
		50			

Левая доковина (продолжение на листе 2)

Условные обозначения

