

Левая боковина (начало)				
	Цепи переменного тока В1			X2
		1	X2:1	SG5:2
		2	X2:2	SG5:4
		3	X2:3	SG5:6
		4	X2:4	SG5:8
		5	X2:5	SG5:10
		6	X2:6	SG5:12
		7		
		8		
	Цепи переменного тока В2			X2
		9	X2:9	SG6:2
		10	X2:10	SG6:4
		11	X2:11	SG6:6
		12	X2:12	SG6:8
		13	X2:13	SG6:10
		14	X2:14	SG6:12
		15		
		16		
	Цепи переменного тока Т(АТ)			X2
		17	X2:17	SG7:2
		18	X2:18	SG7:4
		19	X2:19	SG7:6
		20	X2:20	SG7:8
		21	X2:21	SG7:10
		22	X2:22	SG7:12
		23		
		24		
	Цепи переменного напряжения			X2
		25	X2:25	SG8:2
		26	X2:26	SG8:4
		27	X2:27	SG8:6
		28	X2:28	SG8:8
	Цепи оперативного тока			X2
		29	X2:29	UZ2:1
		30	X2:30	SG5:14
		31		
		32		
		33		
		34	X2:34	A2-M6.XB-1
		35		
		36		
		37		
		38	X2:38	A2-M6.XB-3
		39	X2:39	A2-M6.XB-5
		40		

Левая боковина (продолжение на листе 2)

Правая боковина (начало)				
X1	Цепи переменного тока В1			
SG1:2	X1:1	1		
SG1:4	X1:2	2		
SG1:6	X1:3	3		
SG1:8	X1:4	4		
SG1:10	X1:5	5		
SG1:12	X1:6	6		
		7		
		8		
X1	Цепи переменного тока В2			
SG2:2	X1:9	9		
SG2:4	X1:10	10		
SG2:6	X1:11	11		
SG2:8	X1:12	12		
SG2:10	X1:13	13		
SG2:12	X1:14	14		
		15		
		16		
X1	Цепи переменного тока Т(АТ)			
SG3:2	X1:17	17		
SG3:4	X1:18	18		
SG3:6	X1:19	19		
SG3:8	X1:20	20		
SG3:10	X1:21	21		
SG3:12	X1:22	22		
		23		
		24		
X1	Цепи переменного напряжения			
SG4:2	X1:25	25		
SG4:4	X1:26	26		
SG4:6	X1:27	27		
SG4:8	X1:28	28		
X1	Цепи оперативного тока			
UZ1:1	X1:29	29		
SG1:14	X1:30	30		
		31		
		32		
		33		
A1-M6.XB-1	X1:34	34		
		35		
		36		
		37		
A1-M6.XB-3	X1:38	38		
A1-M6.XB-5	X1:39	39		
		40		

Правая боковина (продолжение на листе 2)

Условные обозначения

