

Левая боковина (начало)						
	Цепи переменного тока В1			X		
		1	X:1	SG1:2	#	
		2	X:2	SG1:4	#	
		3	X:3	SG1:6	#	
		4	X:4	SG1:8	#	
		5	X:5	SG1:10	#	
		6	X:6	SG1:12	#	
			7			
			8			
	Цепи переменного тока В2			X		
		9	X:9	SG2:2	#	
		10	X:10	SG2:4	#	
		11	X:11	SG2:6	#	
		12	X:12	SG2:8	#	
		13	X:13	SG2:10	#	
		14	X:14	SG2:12	#	
			15			
			16			
	Цепи переменного тока Т(АТ)			X		
		17	X:17	SG3:2	#	
		18	X:18	SG3:4	#	
		19	X:19	SG3:6	#	
		20	X:20	SG3:8	#	
		21	X:21	SG3:10	#	
		22	X:22	SG3:12	#	
			23			
			24			
	Цепи переменного напряжения			X		
			25	X:25	SG4:2	+
			26	X:26	SG4:4	+
			27	X:27	SG4:6	+
			28	X:28	SG4:8	+
	Цепи оперативного тока			X		
			29	X:29	UZ1:1	+
			30	X:30	SG1:14	—
			31			
			32			
			33			
			34	X:34	A1-M6.XB-1	—
			35			
			36			
			37			
			38	X:38	A1-M6.XB-3	—
			39	X:39	A1-M6.XB-5	—
			40			
			41			
			42			
			43			
			44			
			45			
			46			

Левая боковина (продолжение на листе 2)

Условные обозначения

