

2 секция. Левая боковина (начало)

	Цепи переменного тока В1			X	
		1	X:1	SG1:2	#
		2	X:2	SG1:4	#
		3	X:3	SG1:6	#
		4	X:4	SG1:8	#
		5	X:5	SG1:10	#
		6	X:6	SG1:12	#
		7			
		8			
	Цепи переменного тока В2			X	
		9	X:7	SG2:2	#
		10	X:8	SG2:4	#
		11	X:9	SG2:6	#
		12	X:10	SG2:8	#
		13	X:11	SG2:10	#
		14	X:12	SG2:12	#
		15			
		16			
	Цепи переменного тока В3			X	
		17	X:17	SG3:2	#
		18	X:18	SG3:4	#
		19	X:19	SG3:6	#
		20	X:20	SG3:8	#
		21	X:21	SG3:10	#
		22	X:22	SG3:12	#
		23			
		24			
	Цепи переменного тока В4			X	
		25	X:25	SG4:2	#
		26	X:26	SG4:4	#
		27	X:27	SG4:6	#
		28	X:28	SG4:8	#
		29	X:29	SG4:10	#
		30	X:30	SG4:12	#
		31			
		32			
	Цепи переменного тока В5			X	
		33	X:33	SG5:2	#
		34	X:34	SG5:4	#
		35	X:35	SG5:6	#
		36	X:36	SG5:8	#
		37	X:37	SG5:10	#
		38	X:38	SG5:12	#
		39			
		40			

2 секция. Левая боковина (продолжение на листе 2)

2 секция. Правая боковина (начало)

Х	Цепи фиксации присоединений		
A1-M9.XB:15	X:223	241	
		242	
		243	
A1-M9.XB:11	X:226	244	
A1-M9.XB:13	X:227	245	
		246	
		247	
		248	
		249	
		250	
		251	
		252	
		253	
		254	
		255	
		256	
		257	
		258	
		259	
		260	
A1-M6.XB:17	X:261	261	
A1-M6.XB:18	X:262	262	
A1-M6.XB:19	X:263	263	
A1-M6.XB:20	X:264	264	
A1-M6.XB:21	X:265	265	
A1-M6.XB:22	X:266	266	
A1-M6.XB:23	X:267	267	
A1-M6.XB:25	X:268	268	
A1-M6.XB:26	X:269	269	
A1-M6.XB:27	X:270	270	
A1-M6.XB:28	X:271	271	
A1-M6.XB:29	X:272	272	
A1-M6.XB:30	X:273	273	
A1-M6.XB:31	X:274	274	
A1-M7.XB:1	X:275	275	
A1-M7.XB:2	X:276	276	
A1-M7.XB:3	X:277	277	
A1-M7.XB:4	X:278	278	
A1-M7.XB:5	X:279	279	
A1-M7.XB:6	X:280	280	
A1-M7.XB:7	X:281	281	
A1-M7.XB:9	X:282	282	
A1-M7.XB:10	X:283	283	
A1-M7.XB:11	X:284	284	
A1-M7.XB:12	X:285	285	
A1-M7.XB:13	X:286	286	
A1-M7.XB:14	X:287	287	
A1-M7.XB:15	X:288	288	

2 секция. Правая боковина (продолжение на листе 2)

Условные обозначения

