FG-KAL / KBM SERIES C FUNCTIONS

	DISPLAY		
With the display off hold <cal> + <mode> and then press <on off=""></on></mode></cal>	Version		
<mode></mode>	Display		
<print></print>	CHECK		
<print></print>	Init		
<print></print>	C-Fnc		
<mode></mode>	C1	Cal	0 : Enable
			1 : Disable
<mode></mode>	C2	(TARE) key	0 : Disable
			1 : Enable
<mode></mode>	C3	Model	0:30 kg
			1 : 60 kg
			2 : 150 kg
			3 : 200 kg
<mode></mode>	C4	Metric	0: Metric
			1 : Non Metric
<mode></mode>	C5	Zero Tracking	0 : Disable
			1 : Enable
<mode></mode>	C6	Decimal point	0:"•"
			1:","
<mode></mode>	C7	Fixed Range	0
<mode></mode>	END		
<mode></mode>	C-Fnc		
<zero> store data</zero>	Weigh Mode		