## ADM Toolbox 2008



## **AD4406 Auto Power ON**

The AD4406 requires an operator to press the ON/OFF button after the mains power has been applied to turn the display on.

Problem: Weighing applications where no operator is present.


24 Hour un-manned weighbridges systems

Remote silo level monitoring for tanker delivery systems Batching systems with auto restart after power failure

The AD4406 requires a Main Board modification.

While this is quite a simple modification the Main Board is still a precise and sensitive piece of equipment and as thus, this modification should ONLY be performed by qualified personnel.

"If you have any doubt as to how to carry out this procedure, please contact A&D Mercury's Service Department so as not to compromise the warranty on your A&D product".



## Modification Explanation:

Step 1: Remove the power adaptor which is connected to the mains supply.

Remove the battery pack if it is fitted.

Step 2: Remove any fitted option card.

Step 3: Remove the four screws that secure the front bezel to the rear housing.


**Note:** There is one screw hidden under the calibration cover plate.


Step 4: Locate the position of JP1 on the main board.

Step 5: Use a soldering iron with fresh solder to produce a short on JP1.

Step 6. Re-assemble the AD4406 and apply power.

The AD4406 will now turn on immediately without pressing the On/Off button when power is applied.







Head Office & Factory Victorian Office

32, Dew Street 39 Bakehouse Road

Fax (08) 8352 7409

Thebarton Kensington

South Australia 5031 Victoria 3031

Tel. (08) 8301 8100 Tel. (03) 9372 1522

Fax (03) 9372 1193

Unit 4, 14 Abbott Road Seven Hills New South Wales 2147

**New South Wales Office** 

Tel. (02) 9674 5466 Fax (02) 9674 2544

