HL i Model Calibration Procedure

- Press and hold the RE-ZERO key, press the UNITS hidden key and the ON:OFF key.
- 2. **LAL** appears. Press **RE-ZERO** key.
- 3. [AL Dappears. Press RE-ZERO key.
- 4. LAL F appears. Place capacity mass on scale and press **RE-ZERO** key, e.g. HL 200=200 g.
- 5. LAL End: Turn scale off then on, scale will be weighing normally.