

Dr. Mukta Bansal

School of Chemistry, Chemical Engineering & Biotechnology (CCEB)

Office: N1.2 - B2 - 28

Email: mbansal@ntu.edu.sq

## **Learning Objectives**

At the end of this chapter, you will be able to:

- Explain the different types of standard process inputs
- Explain the response of first-order processes
- Explain the response of integrating processes
- Explain the response of second-order processes

## **Chapter Overview**

- 1. Standard process inputs:
  - Step input
  - Ramp input
  - Rectangular pulse
  - Sinusoidal input
  - Impulse input
- 2. Response of first-order processes:
  - Step response
  - Ramp response
  - Sinusoidal response

#### **Chapter Overview**

- 3. Response of integrating processes
- 4. Response of second-order processes
  - Example of non-interacting tanks
  - Three cases of second-order process
    - Overdamped
    - Critically damped
    - Underdamped

#### **Response of Processes**


- It is important to know how the process responds to changes in the process inputs.
- A number of standard types of input changes are widely used for two reasons:
  - They are representative of the types of changes that occur in plants.
  - They are easy to analyze mathematically.
- Process input falls into two categories:
  - Input that can be manipulated to control the process and
  - Input that are not manipulated (disturbance).

## 1. Standard Process Input: Step Input

 A sustained and sudden change in a process variable can be approximated by a step change of magnitude, M.

$$u_S = \begin{cases} 0 & t < 0 \\ M & t \ge 0 \end{cases} \tag{4-4}$$

$$U_S(s) = \frac{M}{s} \tag{4-6}$$




## **Step Input (Cont'd)**

- Special Case: If M = 1, we have a "unit step change".
- Example:
  - A reactor feedstock is suddenly switched from one supply to another, causing sudden changes in feed concentration, flow, etc.
  - The heat input to the stirred-tank heating system is changed from 8000 to 10,000 kcal/hr by changing the electrical signal to the heater.

$$q(t) = 8000 + 2000u(t),$$
  $u(t) = unit step$   
 $q'(t) = q - \bar{q} = 2000u(t),$   $\bar{q} = 8000 \, kcal/hr$ 

## **Standard Process Input: Ramp Input**

- Industrial processes often experience "drifting disturbances", that is, relatively slow changes up or down for some period of time.
- The rate of change is approximately constant.



#### Ramp Input (Cont'd)

 Drifting disturbance is approximated by a ramp function:

$$u_R(t) = \begin{cases} 0 & t < 0 \\ at & t \ge 0 \end{cases} \tag{4-7}$$

$$U_R(s) = \frac{a}{s^2} \tag{4-8}$$

- Examples
  - Gradual change in feed composition, heat exchanger fouling, catalyst activity, and ambient temperature.

## **Standard Process Input: Rectangular Pulse**


 Processes are subjected to a sudden step change and then returns to its original value.

$$u_{RP}(t) = \begin{cases} 0 & for & t < 0 \\ h & for & 0 \le t < t_w \\ 0 & for & t \ge t_w \end{cases}$$
 (4-9) 
$$U_{RP}(s) = \frac{h}{s} [1 - e^{-t_w s}]$$
 (4-11)

- Examples:
  - Reactor feed is shut off for one hour.
  - The fuel gas supply to a furnace is briefly interrupted.

## **Standard Process Input: Impulse Input**

- Here,  $u_I(t) = \delta(t)$  and  $U_I(s) = 1$ .
- It represents a short and transient disturbance.
- It is the limit of a rectangular pulse for  $t_w \to 0$  and  $h = 1/t_w$ .
- Examples:
  - Electrical noise spike in a thermo-couple reading and
  - Injection of a tracer dye.
- For this case, Y(s) = G(s).



## **Standard Process Input: Sinusoidal Input**

- Processes are also subject to periodic, or cyclic, or disturbances.
  - Approximated by a sinusoidal function:

$$u_{sin}(t) = \begin{cases} 0 & t < 0 \\ A\sin\omega t & t \ge 0 \end{cases}$$
 (4 - 14)

• A = amplitude,  $\omega = \text{angular frequency}$ ,  $P = \text{period} = 2\pi/\omega$ 

$$U_{sin}(s) = \frac{A\omega}{s^2 + \omega^2} \tag{4-15}$$

- Examples:
  - 24 hour variations in cooling water temperature
  - 60-Hz electrical noise

#### 2. Response of First-Order Processes

Standard form in ODE representation


$$\tau \frac{dy(t)}{dt} + y(t) = Ku(t)$$

$$\downarrow \qquad \qquad \downarrow \qquad \qquad \qquad \qquad \qquad \downarrow \qquad \qquad \qquad \qquad \downarrow \qquad \qquad \qquad \downarrow \qquad \qquad \qquad \qquad \downarrow \qquad \qquad \qquad \qquad \qquad \downarrow \qquad \qquad \qquad \qquad \qquad \downarrow \qquad \qquad \qquad \downarrow \qquad \qquad \qquad \qquad \qquad \downarrow \qquad \qquad \qquad \qquad \qquad \qquad$$

$$G(s) = \frac{Y(s)}{U(s)} = \frac{K}{\tau s + 1}$$

- K Process Gain
  - Ultimate value of the response (new steady state) for a unit step change in the input.
- τ Time Constant
  - Measure of the time necessary for the process to adjust to a change in its input.

## **Example of First-Order Processes**



Stirred tank

$$K = \frac{1}{wC}$$
 and  $\tau = \frac{V\rho}{w}$ 

## **Step Response of First-Order Processes**

For a step input of magnitude M, i.e.

$$U(s) = \frac{M}{s}$$

$$Y(s) = \frac{KM}{(\tau s + 1)s}$$


PFE 
$$Y(s) = KM\left(\frac{1}{s} - \frac{\tau}{\tau s + 1}\right)$$

Inverse LT 
$$y(t) = KM(1 - e^{-t/\tau})$$
 Step response of a first-order process

first-order process

## **Characteristics of Step Response**

$$y(t) = KM(1 - e^{-t/\tau})$$



t/τ	$y/y_{\infty}$
1	0.632
2	0.865
3	0.950
4	0.982
5	0.993

Essentially settled

- First-order process does not respond instantaneously to a sudden change in its input
- $y_{\infty} = y(t = \infty) = KM$  (new steady state)
- Larger  $\tau$  implies slower response
- Effect of K and  $\tau$  on the response

## **Food for Thought**

Consider two first-order processes:

$$G_1(s) = K_1/(\tau_1 s + 1)$$

$$G_2(s) = K_2/(\tau_2 s + 1)$$

- The step response of  $G_1(s)$  reaches 50% of its ultimate value in 10 min. When will step response of  $G_2(s)$  reach 50% of its ultimate value?, if:
  - Case 1:  $K_2 = 2K_1$  and  $\tau_1 = \tau_2$
  - Case 2:  $K_2 = K_1$  and  $\tau_1 = 2\tau_2$

#### **Recap of First-Order Processes**

In response to a step change in input:

- The output reaches a new steady state, KM.
- The output takes  $\sim 5\tau$  to reach new steady-state.
- The larger the  $\tau$ , the slower is the response.
- The output reaches 63.2% of its final value at time equal to time constant.

#### Ramp Response of First-Order Processes

- Time domain  $u(t) = at, t \ge 0$
- Laplace  $U(s) = a/s^2$   $G(s) = \frac{Y(s)}{U(s)} = \frac{K}{\tau s + 1}$   $Y(s) = \frac{K}{\tau s + 1}U(s) = \frac{Ka}{s^2(\tau s + 1)}$
- Partial fraction

$$Y(s) = \frac{Ka}{s^2(\tau s + 1)} = \frac{Ka\tau^2}{\tau s + 1} - \frac{Ka\tau}{s} + \frac{Ka}{s^2}$$
 (4 – 20)


Response

$$y(t) = Ka\tau(e^{-t/\tau} - 1) + Kat$$
 (4 – 21)

• Large value of time  $(t \gg \tau)$ 

$$y(t) = Ka(t - \tau) \tag{4 - 22}$$

## Ramp Response of First-Order Processes (Cont'd)



Ramp response of a first-order process (Comparison of input and output)

Source: Seborg, D. E., Edgar, T. F., Mellichamp, D. A., & Doyle, F. J., (2011). *Process dynamics and control* (3rd ed.)(pp.111). Hoboken, NJ: Wiley

#### **Sinusoidal Response of First-Order Processes**

- For a sine input  $U(s) = \frac{\omega}{s^2 + \omega^2}$
- Output is

$$Y(s) = \frac{K_p}{\tau s + 1} \cdot \frac{\omega}{s^2 + \omega^2} = \frac{\alpha_0}{\tau s + 1} + \frac{\alpha_1 s}{s^2 + \omega^2} + \frac{\alpha_2}{s^2 + \omega^2}$$

Partial fraction

$$\alpha_0 = \frac{\omega K_p \tau^2}{\omega^2 \tau^2 + 1}$$

$$\alpha_1 = \frac{-\omega K_p \tau}{\omega^2 \tau^2 + 1}$$

$$\alpha_2 = \frac{\omega K_p}{\omega^2 \tau^2 + 1}$$

#### Sinusoidal Response of First-Order Processes (Cont'd) €

• Inverting:

This term dies out for large 't' 
$$y(t) = \frac{K_p \omega \tau}{\omega^2 \tau^2 + 1} e^{-t/\tau} + \frac{K_p}{\sqrt{\omega^2 \tau^2 + 1}} \sin(\omega t + \phi)$$
 
$$\phi = -arc \tan(\omega \tau)$$

- Note that "y" is not a function of t but of t and  $\omega$ .
- For large t, y(t) is also sinusoidal, output sine is attenuated by:

$$\frac{Kp}{\sqrt{\omega^2 \tau^2 + 1}}$$
 (fast vs. slow  $\omega$ )

#### 3. Response of Integrating Processes


Recall the tank with pump attached to the outflow line.

$$\frac{d(\rho V)}{dt} = pq_i - pq \qquad (2 - 53)$$

Assume constant density and constant A,


$$AsH'(s) = Q'_i(s), \qquad \frac{H'(s)}{Q'_i(s)} = \frac{1}{As}$$

- Integrate models characterized by the term 1/s.
- Do not have a steady-state gain.



#### 4. Second-Order Processes

- Second-order TF can arise whenever two first-order processes are connected in series.
  - Example: Two stirred-tank blending processes:



#### Second-Order Processes (Cont'd)

 Alternatively, a second-order process transfer function will arise upon transforming a second-order ODE:

$$\tau^2 \frac{d^2 y(t)}{dt^2} + 2\zeta \tau \frac{dy(t)}{dt} + y(t) = Ku(t)$$



$$G(s) = \frac{Y(s)}{U(s)} = \frac{K}{\tau^2 s^2 + 2\zeta \tau s + 1}$$
 (4 – 40)

- Three adjustable parameters:
  - Static gain (K) and time constant  $(\tau)$ : are same as first-order processes.
  - Damping factor (ζ, zeta): determines whether the system has <u>oscillatory behavior</u> or not.

#### Second-Order Processes (Cont'd)

• Eqn (4-39) and (4-40) differ only in the form of denominator. Equating the denominators:


$$\tau^2 s^2 + 2\xi \tau s + 1 = (\tau_1 s + 1)(\tau_2 s + 1) \qquad (4 - 41)$$

• Equating:

$$\tau = \sqrt{\tau_1 \tau_2} \tag{4-42}$$

$$\xi = \frac{\tau_1 + \tau_2}{2\sqrt{\tau_1 \tau_2}} \tag{4 - 43}$$

## **Typical Example: Non-Interacting Tanks**



#### **Three Important Cases of Second-Order Processes**

$$\tau^2 s^2 + 2\zeta \tau s + 1 = 0$$

$$s_1 = -\frac{\zeta}{\tau} + \frac{\sqrt{\zeta^2 - 1}}{\tau}$$
 and  $s_2 = -\frac{\zeta}{\tau} - \frac{\sqrt{\zeta^2 - 1}}{\tau}$ 

#### **Roots**

#### Response

ζ > 1	Distinct real roots	Overdamped or non-oscillatory
$\zeta = 1$	Real and equal roots	Critically damped
ζ < 1	Complex roots	Underdamped or oscillatory

#### **Step Response of Second-Order Processes**

 Consider system response to a step change of magnitude M.

$$U(s) = \frac{M}{s}$$

$$Y(s) = \frac{KM}{(\tau^2 s^2 + 2\zeta \tau s + 1)s}$$

 After inverting to the time domain, the response can be categorized into three classes (depending on the value of zeta).

#### Step Response of Second-Order Processes (Cont'd)

Overdamped (zeta > 1)

$$(\tau^2 s^2 + 2\zeta \tau s + 1) = (\tau_1 s + 1)(\tau_2 s + 1)$$

where 
$$au_1=rac{ au}{\zeta-\sqrt{\zeta^2-1}}$$
  $au_2=rac{ au}{\zeta+\sqrt{\zeta^2-1}}$ 

$$y(t) = KM \left( 1 - \frac{\tau_1 e^{-t/\tau_1} - \tau_2 e^{-t/\tau_2}}{\tau_1 - \tau_2} \right)$$
 (4 - 48)

$$y(t) = KM \left[ 1 - e^{-\zeta t/\tau} \left( \cos h \left( \frac{\sqrt{\zeta^2 - 1}}{\tau} t \right) \right. + \frac{\zeta}{\sqrt{\zeta^2 - 1}} \sin h \left( \frac{\sqrt{\zeta^2 - 1}}{\tau} t \right) \right) \right] \quad (4 - 49)$$

## Step Response of Second-Order Processes (Cont'd)

Critically damped (Zeta = 1)

$$y(t) = KM \left[ 1 - \left( 1 + \frac{t}{\tau} \right) e^{-t/\tau} \right] \tag{4-50}$$

#### **Ordinary Differential Equations**


Underdamped (0 ≤ Zeta < 1)</li>

$$y(t) = KM \left[ 1 - e^{-\zeta t/\tau} \left( \cos(\sqrt{1 - \zeta^2} \frac{t}{\tau}) + \frac{\zeta}{\sqrt{1 - \zeta^2}} \sin(\sqrt{1 - \zeta^2} \frac{t}{\tau}) \right) \right]$$


$$(4 - 51)$$

#### **Three Distinct Cases**

$$K = 1, M = 1, \tau = 1$$




#### Step Response of Underdamped Second-Order Processes




Source: Seborg, D. E., Edgar, T. F., Mellichamp, D. A., & Doyle, F. J., (2011). *Process dynamics and control* (3rd ed.)(pp.117). Hoboken, NJ: Wiley

## **Step Response of Critically Damped & Overdamped Second-Order Processes**



Source: Seborg, D. E., Edgar, T. F., Mellichamp, D. A., & Doyle, F. J., (2011). Process dynamics and control (3rd ed.)(pp.118). Hoboken, NJ: Wiley

## **Second-Order Processes: Effect of ξ**



- $y_{\infty} = y(t = \infty) = KM$  (new steady state).
- Oscillations and response exceeds final value (overshoot), when ζ < 1 (underdamped).</li>
- Response becomes sluggish as  $\zeta$  and t increases.
- Fastest response without oscillations and overshoot, when  $\zeta = 1$  (critically damped).


#### **Take Home Message**

- For zeta > 1
  - Response is non-oscillatory or overdamped.
  - Response is delayed initially (compared to 1st order) and becomes more sluggish as zeta increases.
  - Approaches its final value (KM) asymptotically as t approaches infinity.
- For zeta = 1
  - Response non-oscillatory; rapid approach to final value without oscillations.
- For zeta < 1</li>
  - Response is oscillatory and oscillations increases as zeta decreases.
  - Response is initially faster.

## Why Study Underdamped Systems?

- Very few processes encountered in chemical industries exhibit natural (when control is not applied) underdamped behavior.
- Feedback controller may cause the closed-loop system to exhibit underdamped dynamics.
- Control engineers often attempt to make the response of the controlled variable to a set point change approximate the ideal step response of an underdamped second-order system, that is, make it exhibit a prescribed amount of overshoot and oscillation.

## **Underdamped Response Characteristics**




Source: Seborg, D. E., Edgar, T. F., Mellichamp, D. A., & Doyle, F. J., (2011). *Process dynamics and control* (3rd ed.)(pp.118). Hoboken, NJ: Wiley

## **Underdamped Response Characteristics**

- Rise Time  $(t_r)$ 
  - Time when output "first" reaches the new steady-state value.
- Time to First Peak  $(t_p)$ 
  - Time when output reaches its first maximum value.

$$t_p = \frac{\pi\tau}{\sqrt{1-\zeta^2}} \qquad (4-52)$$

- Settling Time (t<sub>s</sub>)
  - Time required for output to reach and remain inside a band with width equal to  $\pm 5\%$  of the total change in y.



## **Underdamped Response Characteristics**


- Overshoot
  - a/b (% overshoot is 100a/b)

$$\frac{a}{b} = exp\left(\frac{-\pi\zeta}{\sqrt{1-\zeta^2}}\right)$$

$$(4 - 53)$$

- Decay Ratio
  - c/a, where c is height of second peak

$$\frac{c}{a} = exp\left(\frac{-2\pi\zeta}{\sqrt{1-\zeta^2}}\right) = \frac{a^2}{b^2} \tag{4-54}$$



- Period of Oscillation (P)
  - Time between two successive peaks or valleys of the response

$$p = \frac{2\pi\tau}{\sqrt{1-\zeta^2}}\tag{4-55}$$

#### **Summary of Second-Order Processes for Step Input**

In response to a step change in input:

- The output reaches a new steady state, KM.
- Increasing  $\zeta$  and  $\tau$  makes the response more sluggish.
- Oscillations and overshoot are observed, if ζ < 1 (underdamped).
- Fastest response with no oscillations and overshoot, if  $\zeta = 1$  (critically damped).


## **Chapter Summary**

- Transfer functions can be used to obtain responses to any type of input change
- Important types of input functions
- Responses of first-order, second-order to these types of input functions
- Integrating processes
- Suggested Reading: Chapter 4 of Seborg

#### **Exercise**

 Find overshoot, decay ratio, rise time, settling time and period of oscillation.

$$G(s) = \frac{Y(s)}{U(s)} = \frac{2}{s^2 + 0.4s + 1}$$



## **Review Questions**





- - 1 Go to wooclap.com
  - 2 Enter the event code in the top banner

Event code

CH3101CHAPTER5



The End