

Tool change starts.



Solenoid valve SL09 (Spindle Taper Cleaning) is energized and air is supplied to Spindle Taper.

DO: SL09 0→1



Tool being changed.



Machine Controller confirms completion of tool clamping.



Solenoid valve SL09 (Spindle Taper Cleaning) is de-energized and air supply stops.



Tool change operation completed.