

TAKING MEN'S MEASUREMENTS

COAT MEASURES

Take these measures over a shirt

The tape should be horizontal to the floor when taking circumference measurements

- **A B—Chest** -Over the prominent part of shoulder blades and chest.
- **C D—Coat Waist** Over the prominent point of waist.
- **E F**—**Hip** -Over most prominent point of hip.

Take these measures with a coat on.

- **H I—Half Back Width** From center back seam, at shoulder blade level, to sleeve seam.
- **I K—Sleeve Length** Bending the arm, continue from the sleeve seam, along elbow seam of sleeve, to the hollow beyond the wrist bone.

TROUSER MEASURES

- **A B—Waist** -At the top of the hip bone.
- **C D—Hip** -Taken over most prominent point of hip.

<u>To be taken without shoes</u>

- **E F—Oustside Leg** From the top of the hip bone to the floor.
- **G F—Inside Leg** From the crotch point to the floor.
- **G I—Inside Leg to Knee** From the crotch point to the crease in the knee when bent. **HEIGHT**

WAISTCOAT MEASURES

Chest, waist and hip

