

== Digital Moisture Meter ==

7. WHEAT 13.5
STAG-NO: 0012

Operating Instructions-

1. Moisture meter switch on, with the help of on / off switch.
2. Wait for the sample to take until the automatic calibration process is done.
3. Select commodity with the help of Hot Key Switch or Mode Option.
4. Select the Volume of sample displayed in the display.
5. Compress the sample as per thickness setting chart.
6. Press the Read Switch and wait till Moisture % is Displayed.
7. After the display of Moisture %, submit a Sample Number / Lot Number with the help of up / down switches
8. In case of display showing.

ER-1: Under Range and Sample is not properly pressed

ER-2: Try Different Sample.

ER-3: Over Range or plunger shorted with the test cup.

Any Other Query: Read Manual Carefully.

Precautions:- Switch off Moisture Meter when not in use

MODE

HK-1

HK-2

HK-3

RESET

UP

DOWN

READ

Orca
STRUMENT

AN ISO 9001 : 2015 CERTIFIED COMPANY
CE CERTIFIED COMPANY

