---
doc_id: pdf-sop-loto
title: LOTO Safety SOP (PDF)
model: X100
doc_type: sop
version: 2.1
section: Lockout Tagout and Zero Energy
page: 3

Lockout Tagout and Zero Energy

Before inspecting the fan, fuse, or electrical connections:

1. Notify the customer and stop the machine.
2. Open the main disconnect and apply a lock and tag.
3. Wait five minutes and verify DC bus voltage is below 36 V.
4. Measure fan terminals with a multimeter.
5. Confirm the fan wheel is completely stopped.

Do not bypass F3. Do not hot-plug the fan connector. Do not remove the fan before zero energy is verified.