hyatt cheat sheet							
motion	G0	Rapid positioning					
motion	G1	Linear interpolation					
motion	G2	Clockwise circular/helical interpolation					
motion	G3	Counterclockwise circular/Helical interpolation					
non-modal		Dwell					
non-modal		Coordinate system origin setting					
plane	G17	XY Plane select					
plane	G18	XZ plane select					
plane	G19	YZ plane select					
unit	G20	Inch unit					
unit	G21	Millimeter unit					
non-modal		Return home					
		Reference axes					
non-modal	G30	Go Predefined Position					
non-modal	G30.1	Set Predefined Position					
probe	G31	Straight probe					
probe		probe toward workpiece, stop on contact, signal error if failure					
probe		probe toward workpiece, stop on contact					
probe		probe away from workpiece, stop on loss of contact, signal error if failure					
probe		probe away from workpiece, stop on loss of contact					
cutter/tool	G40	Cancel cutter radius compensation					
cutter/tool	G43.1	Apply tool length offset (plus)					
cutter/tool	G49	Cancel tool length offset					
non-modal		Move in absolute machine coordinate system					
coordinate		Use fixture offset 1					
coordinate		Use fixture offset 2					
coordinate		Use fixture offset 3					
coordinate		Use fixture offset 4					
coordinate	G58	Use fixture offset 5					
coordinate	G59	Use fixture offset 6 / use general fixture number					
motion	G80	Cancel motion mode (including canned cycles)					
distance	G90	Absolute distance mode					
distance	G91	Incremental distance mode					
arc	G91.1	Arc IJK Distance Mode					
non-modal	G92	Offset coordinates and set parameters					
non-modal	G92.1	Cancel G92 etc.					
feed	G93	Inverse time feed mode					
feed	G94	Feed per minute mode					
program	MO	Program stop					
program	M1	Optional program stop					
program	M2	Program end					
spindle	МЗ	Rotate spindle clockwise					
spindle	M4	Rotate spindle counterclckwise					
spindle	M5	Stop spindle rotation					
coolant	M7	Mist coolant on					
coolant	M8	Flood coolant on					
coolant	M9	All coolant off					
program	M30	Program end and Rewind					
setting	Tx	Tool select					
setting	Sx	Spindle speed					
setting	Fx	Feed rate					
grbl	\$G	View gcode parser state					
grbl	\$#	View gcode parameters					
grbl	\$H	Home cycle					
grbl	\$X	Kill alarm lock					
grbl	?	Status Report Query					
grbl	~	Cycle State/Resume					
grbl	!	Feed hold					
-							