

STANDARD OPERATING PROCEDURE FOR FIT UP

- Recommended PPEs to be used.
- Before starting fit up process check for availability of material and material free from oils, rusts, pitting, and edge preparation other bending, camber process etc.
- Ensure that the correct drawing, drawing revision number and control copy on drawing.
- All the assemblies to be manufactured using proper jigs and fixtures only.
- Check for the calibration status for the jigs and fixtures.
- Use the calibrated instruments for fit up.
- Only qualified welders should perform the fit up process.
- Start the fit up of subassemblies and then final assemblies as per the drawing layout.
- Before fit up assemblies, remove the scales of the plates wherever welding is done.
- After fit up enmark the part number and part name of the specified location.
- Write the welding details such as welding consumables, welding size.
- Arrest the job with proper clamping arrangement to avoid distortions during welding.
- After quality clearance go for full welding.
- Full welding is followed as per the welding sequence.
- After full welding and cooling remove the clamps from the work piece.

