

WORK INSTRUCTIONS FOR MIG (METAL INERT GAS) WELDING

- Recommend PPEs to be used.
- Only qualified welder has to proceed the following instructions given below
- Check manual running of the machine i.e. rotate the coil by operating the torch to check the coil feed rate.
- Check the electrical cables of the machine, collect the job drawing from the production in-charge and check the availability gas cylinder (CO₂-18%, Argon-82%).
- Clean the surface with brush to remove the dust and ensure surface is rust free.
- By EOT crane load the fabricated jobs to the required position on the table/fixer.
- Select the electrode, contact tip and nozzle required and fit in the welding torch.
- Switch ON the main power supply
- Adjust the current and voltage as per the instructions
- Start the machine and set the required speed and feed manually
- After completing the root run check defects like blow holes, under cuts etc.
- Complete the welding for the required weld thickness as per drawing.
- Clean the area from welding internals and clean the welding M/C properly and the cable is proper way.