

STANDARD PROCEDURE FOR PLASMA CUTTING

- Recommended PPEs to be used.
- Load the programme as per the drawing required dimensions.
- Load the raw material using EOT crane with help of magnetic tong and placed on cutting bed.
- switch it to ON fume extraction system.
- Ensure machine is correctly set up for compressed air, nitrogen and oxygen as required.
- Ensure work return cables make firm contact to provide a good electrical connection.
- Metals coated with or containing materials that emit toxic fumes should not be heated or cut unless coating is removed from the work surface.
- Do not leave the plasma cutter running unattended.
- Switch off the machine and fume extraction (where used).
- Turn off air supply and hang up handpiece, hose and welding cables.
- Cleaning of M/C and bed to be carried out once in a month.
- Add to proper place – check to the E stop operation before start using.