

STANDARD OPERATING PROCEDURE FOR PUNCHING TOOL ASSEMBLY

- Use safety helmet, safety shoes and cotton hand gloves & Goggles.
- Identify proper tool from tool room which is to be loaded on the press.
- Tight the strip, punch and punch plate before lifting the tool.
- Lift the tool from tool room using wire rope to ear rings by EOT crane/forklift.
- Keep the press ram in down position and slide in up position.
- Measure the tool height and adjust the press shut height.
- Keep the tool on press bed with forklift and adjust the slide.
- Clamp the tool bottom bolster and top bolster tightly and ensure there is no play and reduce the load.
- Keep one component in the tool and set the required load.
- While removing the tool ensure, top bolster is on the pillars of the bottom bolster die.