

STANDARD OPERATING PROCEDURE FOR CUTTING

- Use PPE's as required.
- Shift the rolled profiles to the cutting center.
- Clamp the profile properly.
- Check the first piece for length.
- If not Ok adjust stopper.
- Proper handling of profile while shifting.
- Placing the profile straight on the cutting bed.
- Proper clamping while cutting.
- Putting stoppers rigidly for final cutting.
- Clean the machine after completing of job.