

STANDARD OPERATING PROCEDURE FOR PUNCHING

- Use Helmet, Gloves, Safety Shoes, Ear plug.
- Shift rolled profiles by EOT crane to the press area.
- Before starting the machines, machine guards / sensors are to be checked thoroughly.
- Punch the holes by using punching tool and the stoppers have to be set according to the drawing dimensions.
- Setting has to be done by using template.
- Check the profile as per the drawing (customer).
- Check the locations of holes die, with tape / fixture.
- First component is to be checked by Quality inspection team, If found OK start the production.
- If found not OK do necessary adjustment.
- At regular intervals profile dimensions should be checked.
- Punching scrap on the bed should be removed, periodically transfer to collecting bin.
- After completing the job, ensure switching off the machine and clean it properly.

