

STANDARD OPERATING PROCEDURE FOR SPOT WELDING OF LOOSE COMPONENTS OF PROFILES

- Ensure to wear the safety helmet, safety gloves, safety goggles, and safety shoes .
- Shift the profile (i.e. Discharge Electrodes, Collecting Electrodes Etc.,) to the spot welding machine area.
- Clean surface from oil and rust from profile and loose components.
- Set the machine for weld strength as per the chart in case not ok, inform superiors.
- Set the profile into the welding fixture and wherever provided, clamp them.
- If Ok continue to spot weld and check in between for strength.
- If any holes and burns are observed take suitable actions, by ensuring the clearance of the profiles.
- Ensure the pitch of the spot as per drawing.
- Ensure the diameter of the spot as per the drawing.
- Ensure spots are free from holes and hand burning.

