

SAFE OPERATING PROCEDURE FOR WELD REPAIR

1. **Purpose:** To provide guidelines for easy process for Weld Repair.
2. **Scope:** This procedure is applicable to Weld Repair.
3. **Responsibility:** Head Production / Fabrication, Concern Engineers and Shift In - Charge along with their operators are responsible for this activity.
4. **Procedure:**
 - a) Place the steel backing strip at one of the depth of hole and either tack [or] seal welds around the backing strip.
 - b) Gouge a 'U' shaped cavity down to the backing and fill the cavity by welding using a stringer bead technique.
 - c) After the first side is welded, gouge another side to make an " U " shaped cavity completely removing the temporary backing and complete by welding using a stringer bead technique.
 - d) The backing strip material shall have similar composition of base metal.
 - e) Ensure adequate ventilation to remove welding fumes.
 - f) Clear the work area of flammable materials and have fire extinguishing equipment readily available.
 - g) Properly ground the welding equipment to prevent electrical shock
 - h) Use of helmets, hand gloves, goggles and safety shoes is compulsory.
 - i) Proper care must be taken while working / inspecting under overhead cranes.