
SILVERPOINT VACUUM TRUCK SERVICES
STANDARD OPERATING PROCEDURE
Hi-Visibility Apparel Procedure

Proc. No: Vac 4.00.08
Page 1 of 05

RISK RANK 3

PURPOSE:

This procedure provides step-by-step guidance for implementing the High-Visibility Apparel Policy, ensuring all field workers use high-visibility gear that meets or exceeds safety and visibility standards.

COHSR, section 12.17 states: *If there is a risk of injury in a work place that is due to moving vehicles, the employer must provide every person who is granted access to the work place with high visibility safety apparel that meets the requirements set out in CSA Group Standard Z96, High-visibility safety apparel.*

HAZARDS

TYPE	HAZARD	TYPE	HAZARD	TYPE	HAZARD
Physical	Slips, Trips, Falls	Chemical		Property	Equipment
	Mobile Equipment				Third Party Property
	Pinch Points			Productivity	Lost Time
	Night/Low lighting	Biological			
	Noise 82<			Legal	Suspension
	Energy				Out of Service
	Environment	Social			
	Other Workers				
	Work Alone				

REFERENCES

PPE	Prevention	References
Fire Retardant Coveralls	Hazard Assessment	Alberta OH&S
CSA Z96 Hi-Vis Vest	Safety Meeting	Federal OH&S
Steel Toed Boots	Inspection	Task List
Safety Glasses	Maintenance	Standard Operating Procedure
Gloves	FLHA	
Hard Hat	Ear Plugs or Muffs	
Hearing Protection	Training	

You are required to perform at a Job, there are some items that need to be considered:	
Has the Job or Task been Risk Assessed	Is There additional personal
Evaluate the workplace background and conditions, active work zones, Low light levels	Do you have other workers accompanying you; Supervisors, Trainees or 3 rd Party
How far away is the Work Site, Travel Time, ERP Response Time;	Is there mobile equipment in area, loaders, track hoes, casing trucks, vac or water trucks.
Do you have a High Vis Safety Vest for additional personal;	
Do you have a Spotter for tight places;	
Have you implemented Hi Visibility around moving equipment?	

SILVERPOINT VACUUM TRUCK SERVICES
STANDARD OPERATING PROCEDURE
Hi-Visibility Apparel Procedure

Proc. No: Vac 4.00.08
Page 2 of 05

RISK RANK 3

1. Apparel Check Before Starting Work

- Inspect Apparel: “Start Safe, Stay Seen” Your high visibility gear is your first line of protection out there. Taking a moment to check your vest and coveralls before starting the day is an easy way to ensure you’re set up for a safe shift.
- Supervisor Approval: Supervisors will check that everyone’s gear meets CSA Z96 standards so you “Start Safe, Stay Seen”

2. Wearing High-Visibility Apparel

- Gear Up for Every Shift: When you wear high visibility clothing, you’re not just following a rule, you’re making sure everyone sees you clearly. Wearing this gear in active work zones makes sure you’re a priority in everyone’s line of sight.
- Standards Check: If your coveralls do not meet CSA Z96 standards, wear your high visibility vest over your coveralls. This gear keeps you seen and safe.
- Supervisor Check: Supervisors will check that all apparel is in good condition, fits properly, and meets safety standards.

2.1 Mandatory Use of High-Visibility Apparel

- Visibility as a Team: Safety is about working together, and when everyone wears their high visibility apparel, it ensures that every worker stands out. Embrace high visibility gear as essential protection for yourself and everyone around you.
- Entering Active Work Areas: Wear high visibility gear when working or even stepping into a work zone—staying safe means staying seen.
- Two or More, Gear Up: If there are two or more workers onsite, all Silverpoint personal needs to wear their high visibility vests over coveralls. It’s about staying visible to each other and any moving equipment.
- CSA Z96 Compliance: High-visibility apparel must meet CSA Z96 standards for color, reflectivity, and design to ensure visibility in all kinds of light and weather conditions.

3. Identifying Active Work Areas

- Know the Zones That Need Extra Caution: Working near moving equipment or trucks means you need to be highly visible. By knowing the signs of an active work area, you can prepare yourself to be seen and keep your distance from danger zones.
- Signs of Active Work: Active work areas are places with visible, ongoing tasks, like truck and equipment operation or repairs being conducted.
- Presence of Equipment: Trucks, excavators, and parked vehicles with flashing lights indicate active zones. Look for workers wearing high-visibility clothing.
- Increased Noise Levels: Noise as a Clue, machinery, tools, or other equipment noise often signals an active work area.
- Lighting in specific areas: Especially in low-light, marks work areas that need extra caution and require you to “Start Safe, Stay Seen” set up for visibility and safety.

**SILVERPOINT VACUUM TRUCK SERVICES
STANDARD OPERATING PROCEDURE
Hi-Visibility Apparel Procedure**

**Proc. No: Vac 4.00.08
Page 3 of 05**

RISK RANK 3

- Update FLHA: Before work begins, review the layout, boundaries, hazards, access points, PPE requirements, and Lock Out Tag Out procedures with the team.

4. Designated Safe Areas

- Safe Zones for Relaxation and Removal: Safe areas give you a break from high traffic zones and the chance to remove your high visibility gear. Knowing where these zones are helps you make the most of protected spaces onsite.
- When to remove the Vest: You can only take off your high visibility apparel in designated safe areas, where there's no active equipment around.
- Know Your Safe Zones: Safe areas are mentioned in the daily safety meeting. They're defined as "no moving equipment of any type"—your guaranteed breather zone, such as inside your equipment or up on the mud tanks.

5. Situations Requiring High-Visibility Apparel

- Staying Safe Means Staying Seen: Whether helping with a truck or working near traffic or mobile equipment, wearing high visibility gear makes sure everyone knows where you are. Every time you wear it, you're prioritizing your safety and the team's awareness.
- Any Moving Vehicles or Machinery: high visibility vests or coveralls are essential anytime vehicles or machinery are in motion.
- Backing Up Trucks: Whether you're helping a truck back up or operating one, vests are a must to keep you visible.
- Loading Water Trucks: Always have your high visibility gear on when loading near roadsides or around traffic.

6. High-Visibility Apparel Standards

6.1 Special Allowance for Class 1 Level FR Apparel

- **Striping/Bands Requirements:** Stripes or bands Meeting the Highest Standards on Class 1 Level FR garments must be at least 50 mm wide and made of retroreflective and fluorescent materials.
- **Retroreflective Material Width:** Retroreflective material must be at least 19 mm wide and meet photometric standards in Table 5 (Level 2).
- **Flame Resistance:** Garments designed for flame resistance must meet standards such as: CAN/CGSB 155.20, CAN/CGSB 155.22, or NFPA 2112.
- **Garment Labeling:** Garments must be labeled "Class 1 Level FR" to denote compliance with flame resistance and CSA high-visibility requirements.
- **Design Compliance:** Striping/band design must adhere to Clause 4.4.1 of CSA Z96-15.

SILVERPOINT VACUUM TRUCK SERVICES
STANDARD OPERATING PROCEDURE
Hi-Visibility Apparel Procedure

Proc. No: Vac 4.00.08
Page 4 of 05

RISK RANK 3

6.2 Low-Light Visibility

- Stay Bright After Dark: Working in lowlight conditions calls for reflective materials that ensure you're still visible and safe. Our high visibility gear meets these standards, so you're always ready for dusk or night shifts. "Start Safe, Stay Seen"

Class 1 Level FR**



Class 3 Level 2



7. Maintenance and Compliance

Keep high-visibility apparel **clean and well-maintained**. Contaminated or dirty retroreflective materials provide lower visibility.

1. **Daily Check:** Workers must inspect their apparel daily and report any issues.
2. **Supervisor Inspection:** Supervisors conduct regular checks to confirm gear is compliant and functional.

Choose a Low-Light Environment: Reflectivity is best tested in low-light conditions, such as in a darkened room, at dusk, or at night. This helps enhance the visibility of the reflective material when illuminated.

Use a Flash or Strong Light Source: Set up the camera flash or use a strong light source (like a flashlight or car headlights) directed at the coveralls. The flash or light source should be at or near the same angle as the camera to accurately simulate how the stripes will reflect light back toward a viewer.

Position the Camera: Hold or place the camera a few feet away from the coveralls. Make sure the reflective strips are within the camera's frame and well-lit by the light source.

Capture the Image: Take a photo with the flash enabled or while shining the light. High-quality reflective strips should appear bright and highly visible in the photo, whereas worn or ineffective strips will look dull or non-reflective.

SILVERPOINT VACUUM TRUCK SERVICES
STANDARD OPERATING PROCEDURE
Hi-Visibility Apparel Procedure

Proc. No: Vac 4.00.08
Page 5 of 05

RISK RANK 3

Review the Photo: Look for clear, bright reflections from the strips in the image. Reflective stripes in good condition should appear as prominent, highly visible lines. If the reflection appears weak or uneven, the strips may need cleaning, repair, or replacement.

Compare Photos if Needed: If available, compare with previous photos or a standard reference image of well-maintained reflective strips. This can help assess any decline in reflectivity over time.

8. Replacement Protocol: Replace If Needed: Gear that isn't visibly reflective needs to be replaced right away to keep you protected.

9. Additional Safety Protocols

- Gear Designed for Every Condition: Our high visibility apparel has got you covered for different situations, from lowlight to high risk roles.

This specialized gear means you're prepared and fully visible no matter what:

1. Low-Light Conditions: Working in lowlight? Ensure you're using reflective coveralls and high visibility vest that meet visibility standards for those conditions.

2. X-Back Configuration (for Coveralls): X Back for Spotters and other high-risk roles must wear coveralls with an "X" configuration on the back to clearly indicate directionality, ensuring easy identification in machinery-facing or backing scenarios.

By adhering to these guidelines, Silverpoint Energy Services Inc. maintains a high safety standard, ensuring worker visibility and compliance with the latest CSA Z96 standards and Federal Occupational Health and Safety Code.

Work Alone	AB OHS Act, Section 2, 35, and 36	
	AB OHS Code Alberta Regulation 191/2021 Work Alone Part 28	
Right to Refuse	AB OHS Act Part 3 Section 35	
Hazard Prevention	CA Part XIX Hazard Prevention Program 19.1	
Hi Visibility	CA Part II CSA Standard Z96-15 (R2020), High- Visibility Safety Apparel.	

If you have any questions STOP WORK and contact your Supervisor