Calibration steps

1. Warm the instrument for ten minutes.
2. Load the blank specimen.
3. Record the baseline reading.
4. Load the sample specimen.
5. Record the sample reading.
6. Subtract the baseline from the sample.

Keep the original units on every recorded value.