WORK INSTRUCTION Effectivity Date:										tivity Date:	te: September 25, 2024				
			Process Name/Title:		CLAMP ASSEMBLY PROC	ESS				ity Date:			n/a		
			Model code/Part number:	311D /	7L0154-7022 Customer: TRJ	Car Model: TOYOTA-RAV4			. Docu	Document No.:		WI-ENG-PDE-1008			
			Purpose:	PROTOTYPE	☐ PRE-LAUNCH	MASSPE			_	sion No.:)	Page No.:	1 of 6	
		1							<u> </u>				<u> </u>		
PARTS:		,		O (B) Clamp 82711-48210 (B	(B) Clamp 82711-48210 (B); Black tape [5pcs]					JIG:	1. Cla	1. Clamp assembly jig			
NO	NO. PROCESS NAME			WORK PROCEDURE/ ILLUSTRATION						TOOLS/PPE		QUALITY POINTERS			
1		Clamp	Table lay-out	Clamp 82711- 8210 (B)/ Clamp tray Assy pa		ji	32711- / Clamp y		1. 2	afety Instruction Be sure to wear orescribed persons or creative equipment of the control of the	al Imm 1. F befi avo 1. No 2. No in mant ele atte	Please ore st id wro	ent reminders/No e check the clamp art of clamp asse ong use of clamp ing part/tools. ss parts/tools	o first embly to	
Revision History								Prepared by	Reviewed	by	Approved by	Noted by			
										-					
09/25/24	0	PROCES	process from WI-ENG-PDE-94	CESS due to split process. Add	ge Process name/Title from TAPING ASSEMBLY itional Table lay-out; Improve work procedure/Illustration	M. Ariola	C. Villanueva	A. Arañes	n/a	M. Arioja	Joseph) II	for-	A. Araños	n/a	
Eff. Date	Rev. No			Details of Cha	nge	Revised	Reviewed	Approved	Noted	Est. Date:	September 25	, 2024			

				WORK INST	RUCTION	Effectivity Date:	September 25, 2024				
NB		Process Name/Title:			ASSEMBLY PRO	Validity Date:	• •				
		Model code/Part number:	311D /	7L0154-7022		Car Model: TOYOTA-RAV4	Document No.:		WI-ENG-PDE-10	08	
		Purpose:	☐ PROTOTYF	= [PRE-LAUNCH	MASSPRO	Revision No.:	0	Page No.:	2 of 6	
PARTS:		p 82711-48210 (B) [2pcs] p 82711-33650 (B)			3. Black tape [5pcs]		JIG:	1. Clamp as	sembly jig		
NO.	PROCESS NAME			TOOLS/PPE	QUALITY POINTERS						
2	Clamp	Clamp setting	to Clamp location 2. Get 1pc of clar	ap 82711-48210 (B) usino. 1 and 2 using both ap 82711-48210 (B) usion no. 3 and 4 using both	ing right hand then	3. Get 1pc of clamp 82711-33650 (B set to Clamp location no. 5 using both using both hands.) using right hand then h hands.	1. Please before so avoid wr 1. No wrong 2. No wrong 3. No dama	ent reminders/Note e check the clamp tart of clamp asse ong use of clamp use of parts use of tape ged clamp clamp position	first mbly to	

				WORK INSTRUCTION	Effectivity Date:	Effectivity Date: September 25, 2024					
NB		Process Name/Title:		CLAMP ASSEMBLY PR	OCESS	Validity Date:	n/a				
		Model code/Part number:	311D /	7L0154-7022 Customer: TRJ	Car Model: TOYOTA-RAV4	Document No.:		WI-ENG-PDE-10	08		
		Purpose:	PROTOTYPE	☐ PRE-LAUNCH	MASSPRO	Revision No.:	0	Page No.:	3 of 6		
PARTS:	1. Assy 2. Black	parts tape [5pcs]			JIG:	1. Clamp assembly jig					
NO.	P	ROCESS NAME		WORK PROCEDURE/ ILLUS	TRATION	TOOLS/PPE	QUALITY POINTERS				
3	Clamp assembly 1. Get the assy parts using right hand then set into jig usin hands. (See above picture for the correct setting). First the connector 6189-0451 (W) into receiver base 1 then Continue setting the harness into jig. Last, set the hotmelt wires (B/W-G) within the stopper jig then press by the tog clamp. 2. Check the LED light for POWER and CLAMP ON was encountered abnormality, STOP and immediately CALL that attention of the leader. WAIT for further instruction then can the process. Continue if the sequence light on location 1 is			using right hand then set into jig using bot octure for the correct setting). First put 0451 (W) into receiver base 1 then lock. harness into jig. Last, set the hotmelted the stopper jig then press by the toggle that for POWER and CLAMP ON was ON. If ality, STOP and immediately CALL the str. WAIT for further instruction then continued.	3. Hold the tape on the clamp locati Make 3 windings of tape using both Press the SW button after taping. C was ON. 4. Hold the tape on the clamp locatic Make 3 windings of tape using both	h hands then cut the tape. Continue to location 2 if light on no. 2 using right hand. I hands then cut the tape.	1. Please before so avoid wr 1. No wrong 2. No wrong 3. No damage.	ant reminders/No e check the clamp tart of clamp asse ong use of clamp guse of parts guse of tape ged clamp ged clamp ged clamp	o first embly to		

			September 25, 2024								
		Process Name/Title:		CLAMP ASSEMBLY PROC	CESS	Validity Date:	n/a				
		Model code/Part number:	311D /	7L0154-7022 Customer: TRJ	Car Model: TOYOTA-RAV4	Document No.:		WI-ENG-PDE-10	08		
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	0	Page No.:	4 of 6		
PARTS:	1. Assy	parts tape [5pcs]				JIG:	1. Clamp as	sembly jig			
NO.		PROCESS NAME		TOOLS/PPE	QUALITY POINTERS						
3	Clamp		Make 3 windings Press the SW butt was ON. 7. Hold the tape o Make 3 windings	work Procedure/ Illustration of tape using both hands then cut the tape. On after taping. Continue to location 4 if light of tape using both hands then cut the tape. On after taping. Continue to location 4 if light on the clamp location no. 5 using right hand. Of tape using both hands then cut the tape. It is to after taping. Go sound will be heard.	82711-33650 (B) 6. Hold the tape on the clamp locate Make 3 windings of tape using bot Press the SW button after taping. (Iight was ON. 8. After taping, conduct POINT CHE the harness from jig	Stopper jig Switch 4:5022 NBC ion no. 4 using right hand. th hands then cut the tape. Continue to location 5 if	Importa 1. Please before si avoid wr 1. No wrong 2. No wrong 3. No dama	ant reminders/Note check the clamp tart of clamp asse ong use of clamp use of parts use of tape	tes first embly to		

	_			WORK INSTI	RUCTION			Effectivity Date:		September 25, 20	24	
		Process Name/Title:		Validity Date:	n/a							
		Model code/Part number:	311D /	7L0154-7022	ASSEMBLY PR	Car Model:	TOYOTA-RAV4	Document No.:		WI-ENG-PDE-100	08	
		Purpose:	PROTOTYPE		PRE-LAUNCH	MASSPR	RO	Revision No.:	0	Page No.:	5 of 6	
PARTS:	n/a							JIG:	n/a			
NO.	F	PROCESS NAME		⚠ WORK PR	OCEDURE/ ILLUS	TRATION		TOOLS/PPE	QUALITY POINTERS			
4	Clamp	Measurement	Sunprene tube (B) a Sunprene tube (B) a Sunprene tube (B) a One of the sun	3 20±10 4 20±10 9 4 25 ±5 0 \$ 25 ±6	To 77 ±3 B COT (B) #5 w		D COT (B) &	/ 📟	1. Pleasure measure 2. For Hoowarime Docume 1. Pleasure Sub-Ass	ant reminders/No e use calibrated/vo ng tape when fetti ement. atsumono, Nakam	erified ng the ono and ASY-056 for	

